

HARSCO

INDUSTRIAL

Patterson-Kelley

Revised **June 12, 2014**

1004905898

P-K SONIC™ GAS FIRED BOILER



SC-3000/SC-4000

Natural Gas/Propane/Dual Fuel



C.S.A Design-Certified
Complies with ANSI Z21.13/CSA 4.9
Gas-Fired Low Pressure Steam and Hot Water Boilers



ASME Code, Section IV
Certified by Patterson-Kelley



C.S.A Design-Certified
Complies with ANSI Z21.13/CSA 4.9
Gas-Fired Low Pressure Steam and Hot Water Boilers

Part Number

Model Number: _____

Serial Number: _____

Start-Up Date: _____

Harsco Industrial, Patterson-Kelley
155 Burson Street
East Stroudsburg, PA 18301
Telephone: 570.476.7261
Toll Free: 877.728.5351
Fax: 570.476.7247
www.harscopk.com

©2013 Harsco Industrial, Patterson-Kelley
SONIC201

INSTALLATION
& OWNER'S
MANUAL

Installation and Operation Best Practices

Gas

- Use a lock-up type regulator.
- Minimum gas inlet pressure 4.5" wc
- Maximum gas inlet pressure 14" wc

Electrical

- Verify power requirements to boiler.
- Check all electrical connections for tightness as connections may come loose during shipping.

Venting

- Maintain exhaust pressure from -.04" wc to +.22" wc

Hydronics

- Maximum Flow: SC-4000 384 gpm, SC-3000 285 gpm
- Minimum Flow @ Ignition: SC-4000 98 gpm, SC-3000 72 gpm
- Minimum Flow: SC-4000 76 gpm, SC-3000 57 gpm
- Boiler is provided with two (2) relief valves - a Section VIII and a Section IV. Both must be installed as per ASME and local code requirements. A reference to potential installation arrangement is discussed in Section 3.7.3 of this manual.




TABLE OF CONTENTS

1 INTRODUCTION	4		
2 SAFETY	5		
2.2 Safety Precautions	5		
2.3 Training	6		
2.4 Hazard Warnings	6		
2.4.1 Electrical Hazards	6		
2.4.2 Crush Hazards	6		
2.4.3 Bump Hazards	6		
2.4.4 Pressure Hazards	6		
2.4.5 Slip, Fall Hazards	6		
2.4.6 Chemical Hazards	7		
2.4.7 Burn, Fire and Explosion Hazards	7		
3 INSTALLATION	8		
3.1 Receiving and Storage	8		
3.2 Compliance with Codes	8		
3.3 Setup	8		
3.3.1 Foundation	8		
3.3.2 Placement	8		
3.3.3 Clearances	8		
3.4 Electrical Connections	9		
3.4.1 The Power Input Junction Box	9		
3.4.2 High Voltage (TB2) Terminal Block	10		
3.5 Inlet Air and Exhaust Venting	11		
3.5.1 Applicable Codes and Standards	11		
3.5.1.1 Gas Vent Categories	12		
3.5.1.2 Venting Materials for Flue/Exhaust Systems	12		
3.5.2 Combustion Air Materials and Sizes	13		
3.5.2.1 Air Inlet Requirements — United States	14		
3.5.2.2 Air Inlet Requirements – Canada	14		
3.5.3 Flue Venting	15		
3.5.3.1 Vent Sizing	15		
3.5.3.2 Required Clearances	16		
3.5.3.3 Flue Connection	17		
3.5.3.4 Vent Termination	17		
3.5.4 Venting for Multiple Boilers	17		
3.5.5 Sealed Combustion/Direct Vent Systems	18		
3.5.5.1 Inlet Duct Connection to Boiler	18		
3.5.5.2 Intake Duct Materials and Sizes	18		
3.5.6 Removing an Existing Boiler	18		
3.6 Gas Piping	19		
3.6.1 Gas Supply Piping by Installer	19		
3.7 Boiler Water Piping	20		
3.7.1.2 Piping with Air Handling Units	20		
3.7.1.1 Piping with Refrigeration Lines	20		
3.7.2 Boiler Inlet and Outlet Connections	20		
3.7.3 Boiler Water Piping by Installer	21		
3.7.4 Flushing and Filling	21		
3.8 Pre-Start Checklist	22		
3.9 Safety Checks	22		
3.9.1 Test of Ignition Safety System	22		
3.9.2 Test of Low Water Cut-out	22		
3.9.3 Test of High-Limit Control	23		
3.9.4 Test of Gas Pressure Switches	23		
3.10 Initial Adjustments	23		
3.10.1 Operating Temperature Controller	23		
3.10.2 Boiler Set Point	24		
3.10.3 Other CH Parameters	24		
3.10.4 Other Parameters	24		
3.10.5 Additional Menu Items	24		
3.10.6 Service Menu	25		
3.11 Fuel/Air Adjustment	25		
		3.11.1 Gas Pressure Adjustment	25
		3.11.2 Combustion Setup and Adjustment	25
		4 OPERATION	27
		4.1 General	27
		4.1.1 Control Panel Front	27
		4.1.2 Factory Tests	27
		4.2 Normal Lighting and Shut-Down Procedures	27
		4.2.1 Lighting Procedures	27
		4.2.2 Normal Shut Down Procedures	27
		4.3 Emergency Shut Off	27
		4.4 Typical Boiler Operating Conditions	27
		5 MAINTENANCE	28
		5.1 Maintenance and Inspection Schedule	28
		5.1.1 Daily	28
		5.1.2 Weekly	28
		5.1.3 Monthly	28
		5.1.4 Semi-Annually	28
		5.1.5 Annually	29
		5.2 Cleaning the Burner	29
		5.3 Removing the Heat Exchanger	29
		5.4 After Repairs or Maintenance	29
		5.5 Sequence of Operation	30
		5.6 Troubleshooting	30
		5.6.1 Loss of Power	30
		5.6.2 Loss of Water Level	30
		5.6.3 Low Gas Pressure	31
		5.6.4 High Gas Pressure	31
		5.6.5 High Water Temperature	31
		5.6.6 Low Air	31
		5.6.7 Flame Failure	31
		5.6.8 Flame Error	31
		5.6.9 Stack Problem	31
		5.7 Manual Reset Error Codes	32
		5.8 Auto-Reset Error Codes	33
		6 PARTS/TECHNICAL SUPPORT	34
		6.1 Wiring Diagrams	34
		6.1.1 Terminal Block Assignments – Power Block	34
		6.1.2 Terminal Block Assignments — High Voltage Circuit (TB2)	34
		6.1.3 Terminal Block Assignments — Low Voltage Circuit (TB1)	35
		6.1.4 SC-3000 & SC-4000 Transformer Diagram	36
		6.1.5 SC-3000/SC-4000 Boiler Wiring Diagrams	40
		6.1.5.1 SC-3000/SC-4000 Dual Fuel 240 Volt	40
		6.1.5.2 SC-3000/SC-4000 Dual Fuel 480 Volt	42
		6.1.5.3 SC-3000/SC-4000 240 Volt	44
		6.1.5.4 SC-3000/SC-4000 480 Volt	46
		6.2 Boiler Parts List	48
		6.2.1 Main Assembly	48
		6.2.2 Control Panel	49
		6.2.3 SC-3000/SC-4000 Heat Engine	50
		6.2.4 SC-3000 Gas Train	50
		6.2.5 SC-4000 Gas Train	51
		7 LIMITED WARRANTY	52
		APPENDIX 1: MAINTENANCE LOG	54
		APPENDIX 2: BOILER ALTITUDE DERATE SCHEDULE	55
		MULTI-METAL SYSTEMS WATER QUALITY STANDARDS	56

WARNING: If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

WARNING

It is essential to read, understand, and follow the recommendations of this manual before installing, operating, or servicing this equipment.

WARNING

Installation and service must be performed by a qualified and knowledgeable individual who has been certified on the P-K Sonic™ Boiler. The same features which permit this boiler to achieve high-efficiency performance make it unlike most other boilers of this general size, so it is important to understand how this boiler operates.

1 INTRODUCTION

This manual describes the installation and operation of P-K SONIC™ boilers. Natural gas, propane, and dual fuel (natural and propane) units are described. It also includes 208/3/60, 240/3/60, or 480/3/60 voltages for the 3 and 4 million BTUH input boilers. Information for operation with other fuels is included in the various sections of this manual as applicable. If you have any questions on the information contained within, or do not fully and completely understand the content, please contact Harsco Industrial, Patterson-Kelley Technical Service at 570.476.7261 or toll free at 877.728.5351.

The P-K SONIC™ gas fired boilers are fully modulating using variable speed combustion blowers, sophisticated microprocessor controls, modulating gas safety shut off/control valves and a unique stainless steel heat exchanger capable of operating in a fully condensing mode to provide maximum efficiency in a minimum amount of space.

While details may differ slightly, basic operation is the same for all models. Check the rating plate for correct fuel usage and gas pressures.

The boiler is only a part of the complete heating system. This boiler may be fully operational and yet because of poor circulation, control, or other operating characteristics not deliver heat to the desired location. Additional equipment such as temperature sensors, pumps, flow switches, balancing valves, and check valves will be required for satisfactory operation of any system. Harsco Industrial, Patterson-Kelley cannot be responsible for the design or operation of such systems and a qualified engineer or contractor must be consulted.

2 SAFETY

2.1 GENERAL

The SC-3000 and SC-4000 gas-fired boilers must be:

- Installed, operated, and serviced in accordance with instructions contained in this manual and other supplemental manuals.
- Installed by qualified personnel in accordance with designs prepared by qualified facility engineers including: structural, mechanical, electrical, and other applicable disciplines.
- Operated and serviced in accordance with a comprehensive safety program determined and established by the customer. Do not attempt to operate or service until such a program has been established.
- Operated and serviced by experienced, qualified, and properly trained personnel in accordance with all applicable codes, laws, and regulations.

2.2 SAFETY PRECAUTIONS

Provide a suitable location for the boiler, away from normal personnel traffic, with adequate working space, adequate clearances, proper ventilation and lighting, with a structure sufficiently strong and rigid to support the weight of the boiler, all piping, and accessories.



WARNING
Improper use may result in fire or injury.
Read instructions/safety manual before installing, operating or servicing boiler.

<p>AVERTISSEMENT</p> <p>Une installation, un réglage, un changement ou un entretien inappropriés peuvent causer des dommages matériels, des blessures corporelles ou la mort.</p> <p>Lire et bien comprendre le Manuel d'installation et du propriétaire fourni avec cette chaudière. L'installation et le service doivent être effectués par un personnel expérimenté et compétent qui a reçu une formation sur la chaudière de cette série.</p>	 	<p>WARNING</p> <p>Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury or loss of life.</p> <p>Read and understand the installation and Owner's manual provided with this boiler. Installation and service must be performed by experienced and knowledgeable personnel who have been trained on this series boiler.</p>
--	---	--

NOTICE!

Each safety device must be maintained and checked per the recommended schedule. Refer to *Section 5.1* of this manual.

SAFETY FEATURES

It is the responsibility of the customer to maintain the safety features, such as but not limited to: guards, safety labels, safety controls, interlocks, lockout devices, in place and operable.

SAFETY LABELS

The following words are used in this manual to denote the degree of seriousness of the individual hazards.

WARNING

Indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury. This signal word is to be limited to the most extreme situations.

WARNING

Indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, **may** result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE/NOTE - NOTICE

Is the preferred signal word to address practices not related to personal injury. The safety alert symbol is not used with this signal word.

NOTICE!

The safety labels shown below are affixed to your boiler. Although the labels are of high quality, they may become dislodged or unreadable over time. Contact Harsco Industrial, Patterson-Kelley at 570.476.7261 or toll-free at 877.728.5351 for replacements.

<p>AVERTISSEMENT</p> <p>Une installation, un réglage, un changement ou un entretien inappropriés peuvent causer des dommages matériels, des blessures corporelles ou la mort.</p> <p>Lisez et bien comprendre le Manuel d'installation et du propriétaire fourni avec cette chaudière. L'installation et le service doivent être effectués par un personnel expérimenté et compétent qui a reçu une formation sur la chaudière de cette série.</p>		<p>WARNING</p> <p>Improper installation, adjustment, alteration, service, or maintenance can cause property damage, personal injury or loss of life.</p> <p>Read and understand the installation and Owner's manual provided with this boiler. Installation and service must be performed by experienced and knowledgeable personnel who have been trained on this series boiler.</p>
---	---	--

<p>ATTENTION</p> <p>Risque de brûlures. Certains composants sont très chauds. Allouer un temps de refroidissement après l'arrêt et ne pas toucher pendant le fonctionnement.</p>		<p>CAUTION</p> <p>Burn hazard. Some components are hot to the touch. Allow time to cool after shutdown and do not touch during operation.</p>
---	---	--

<p>AVERTISSEMENT</p> <p>Risque électrique. Un contact causera un choc électrique et des blessures. Suivre les procédures de verrouillage/signalisation lors de l'entretien.</p>		<p>WARNING</p> <p>Electrical Hazard. Contact may cause electrical shock and injury. Follow lockout/tagout procedure when servicing.</p>
--	---	--

	<p>WARNING</p> <p>Improper use may result in fire or injury.</p> <p>Read instructions/safety manual before installing, operating or servicing boiler.</p>
---	--

WARNING

Gas may lose its odor. Proper gas sensing equipment and procedures should be used for leak checks.

2.4.5 Slip, Fall Hazards



Tripping hazard! Do not install piping on floor surfaces. Maintain clear path around boiler.

Slip and fall hazard! Use drip pan to catch water while draining the boiler. Maintain dry floor surfaces.

Slip and fall hazard! Do not locate intake or exhaust terminations directly above a walkway; dripping of condensation can cause icing of the walking surface. (See section 3.5)

Fall hazard! Do not stand on boiler.

2.3 TRAINING

Proper training is the best protection against accidents. It is **essential** to read, understand, and follow the recommendations of this manual before installing, operating, or servicing this equipment. Failure to do so could result in fire or explosion and serious injury, death, and/or property damage.

Operating and service personnel must be thoroughly familiar with the basic construction of the SC-3000 and SC-4000 boilers, the use and locations of the controls, the operation of the boilers, adjustment of their various mechanisms, and all applicable safety precautions. If any of the provisions of this manual are not fully and completely understood, contact Harsco Industrial, Patterson-Kelley Technical Service at 570.476.7261 or toll free at 877.728.5351.

2.4 HAZARD WARNINGS

2.4.1 Electrical Hazards



Shock hazard! Properly lockout/tagout the electrical service and all other energy sources before working on or near the boiler.

Shock hazard! Do not spray water directly on this boiler or on any electrical components.

Electrical hazard! Do not alter wiring connections.

2.4.2 Crush Hazards

Lifting hazards! Use properly rated lifting equipment to lift and position the boiler. The load is unbalanced. Test balance before lifting off the floor. Do not allow personnel beneath the lifted load. Refer to approximate weights in the table.

Boiler Size	Weight in Pounds
SC-3000	1,850 lbs
SC-4000	1,900 lbs

2.4.3 Bump Hazard from overhead ductwork and piping.

Install components with adequate vertical clearance.



2.4.4 Pressure Hazards



Pressure hazard! Hot fluids. Install isolation valves on boiler water inlet and outlet. Make sure isolation valves are closed before servicing boiler.

Pressure hazard! Hot fluids. Annually test safety relief valve for proper operation. Do not operate boiler with faulty relief valve.

2.4.6 Chemical Hazards



Chemical hazards from cleaning products. Use caution when cleaning the system. The use of professional assistance is recommended. Use safe procedures for the disposal of all cleaning solutions.

Combustion Condensate – an acidic pH of approximately 3.0 to 5.0 can be expected. Use PVC, CPVC, or other corrosion resistant piping for drainage. Collection and disposal must be in accordance with all applicable regulations. A condensate neutralization kit is available. Please contact your local Harsco Industrial, Patterson-Kelley representative for more information.

2.4.7 Burn, Fire and Explosion Hazards



Burn, fire, and explosion hazards! Installation must be in strict conformance to all applicable codes and standards including NFPA 54, ANSI Z223.1 and CAN/CSA B.149. Install all required vent lines for gas devices. Refer to Section 3.6.



Hazard from incorrect fuels! Possible fire, explosion, overheating, and damage. Do not use any fuels except the design fuels for the unit.

Overfire hazards! High pressure in gas supply could result in overfiring of this or other devices supplied from the same source.

Fire and explosion hazards! Close the main gas shutoff before servicing boiler.

Fire and explosion hazards! Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other gas fired appliance.

Burn hazard! Possible hot surfaces. Do not touch gas vent during firing operation. Use only factory recommended vent components.

Burn hazard! Pipes, vents, and boiler components could be hot. Do not touch piping or stack surfaces during operation or immediately after shutdown of the boiler.

Burn hazard! Hot flue! Use caution when servicing or draining boiler.

Fire and explosion hazards! Use caution when servicing burner. Propane (LPG) is heavier than air and may linger in the combustion chamber, vent lines, or elsewhere.

Gas leak hazard! Make sure the burner is installed correctly and blower/transition is securely fastened following any maintenance performed on them. These connections may leak gas if assembled incorrectly.

Gas leak hazard! All threaded gas connections must be made using a pipe compound that is resistant to liquefied petroleum gas. Do not use Teflon™ tape on threaded gas piping.

Gas leak hazard! Check entire gas train for leaks after installation. If there is a smell of gas, shut down the boiler and obtain immediate assistance from trained service personnel and/or your local fire department.

Overfire hazard! Possible fire and explosion from excess gas pressure. Make sure that gas inlet pressure does not exceed 14 inches wc.

Overfire hazard! Possible fire and explosion. Possible malfunction of regulators and/or gas safety shut off/control valves. Maintain all gas train components in good condition. Do not alter wiring connections. Annual inspection by factory-trained personnel for proper set-up and operation is recommended.

Overfire and underfire hazards! Possible fire, explosion, overheating, and component failure. Do not attempt to adjust firing rate of the boiler. The firing rate must be adjusted only by factory trained personnel.

	<p>WARNING</p> <p>Improper use may result in fire or injury.</p> <p>Read instructions/safety manual before installing, operating or servicing boiler.</p>
---	--

WARNING

Installation and service must be performed by a qualified installer, service agency, or gas supplier.

NOTICE!

Controls and other equipment that are damaged or fail due to weather exposure are not covered by warranty.

WARNING

The wheels provided with this boiler are for positioning purposes only. When positioning this boiler, maintain positive control of it at all times. Do not attempt to move the boiler on surfaces that are not level. Failure to heed this warning could result in personal injury or death.

NOTICE!

The boiler may be installed on a combustible floor; however, the boiler must never be installed on carpeting.

WARNING

Bumping hazard from overhead ducts! Install all components with adequate vertical clearances.

3 INSTALLATION

3.1 RECEIVING AND STORAGE

3.1.1 Initial Inspection

Upon receiving the boiler, inspect it for signs of shipping damage. Some damage may be hidden. Unpack the boiler, open the front and side doors and inspect the boiler. Verify that the total number of pieces shown on the packing slip agrees with those actually received.

3.1.2 Storage Prior to Installation

If the boiler is not installed immediately, it must be stored in a location adequately protected from the weather, preferably indoors. If this is not possible, then it should remain in the shipping container and be covered by a tarpaulin or other waterproof covering.

3.2 COMPLIANCE WITH CODES

The boiler with standard components and with many options complies with American National Standard/CSA Standard ANSI Z21.13/CSA 4.9, latest edition, Gas-Fired Low Pressure Steam and Hot Water Boilers.

The heat exchanger is constructed and stamped in accordance with ASME Boiler and Pressure Vessel Code, Section IV (160 psig maximum operating pressure) and Section VIII.

Installation of the boiler must conform to all the requirements of all national, state and local codes established by the authorities having jurisdiction or, in the absence of such requirements, to the National Fuel Gas Code, ANSI Z223.1/NFPA 54 latest edition in the U.S. In Canada, the equipment shall be installed in accordance with the current Installation Code for Gas Burning Appliances and Equipment, CAN/CSA-B.149, latest edition, and applicable Provincial Regulations for the class, which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.

Where required by local codes, the installation must conform to American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers (ASME CSD-1).

In the Commonwealth of Massachusetts (a) this unit must be installed by a licensed pipe fitter/plumber, (b) field installed gas cocks must be "T" handle type, (c) piping of condensate shall conform to the State Plumbing Code, and (d) refer to the Massachusetts Supplement for further details.

3.3 SETUP

3.3.1 Foundation

Provide a firm, level foundation, preferably of concrete. Lifting the front of the boiler slightly will allow the boiler to be rolled off the shipping skid onto the concrete foundation. Once in position, the wheel bolts may be removed allowing the wheels to recess up into the boiler. The base will sit flat on the provided foundation. If the boiler is to be pulled out for maintenance, the wheels may be left attached.

3.3.2 Placement

The boiler must be level to function properly. Six 9/16" holes in the base may be used for 3/8" seismic anchors.

3.3.3 Clearances


If the boiler is to be installed near combustible surfaces, the minimum clearances shown in the pictures and table below must be maintained. Failure to provide for the service access clearances, even with non-combustible surfaces, may cause future problems servicing the boiler. Maintain a clearance from the vent to combustible

surfaces of 24" or as specified in the vent manufacturer's listed installation instructions. The boiler must be installed in a space large in comparison to the boiler as described in the National Fuel Gas Code, ANSI Z223.1, latest edition.

Table 3.3.3

Type of Surface	Dimensions (inches)			
	A	B	C†	D
Combustible Surfaces Minimum Clearances	30	12*	24	12
Recommended Clearances for Service Access	30	12*	24	12**

Figure 3.3.3



† "C" Space required for pipes, ducts, etc. in this area above the boiler.

* "B" Clearance depends upon exhaust vent configuration.

** Do not put pipes, ducts, vents, etc in this space. Electrical conduit must be installed vertically so that the side doors can be opened. NOTE - Annual maintenance items can be accessed from the front of the boiler.

3.4 ELECTRICAL CONNECTIONS

The SC-3000 and SC-4000 boilers are available as either 208-240 VAC, three phase, 60 hertz or 440-480VAC, three phase, 60 hertz electrical service. Refer to sections 6.1.4, 6.1.5 and 6.2.2 for proper wiring and configuration of the electrical connections. The total operating amperage is indicated on the rating nameplate. Each SC-3000 or SC-4000 boiler requires less than 20 Amps. Before starting the boiler, check to ensure that the proper electrical service is connected to the boiler.

An external electrical disconnect (not supplied with the boiler) is required. The boiler electrical service must be installed and grounded in accordance with local codes or in the absence of such requirements, in the U.S. with National Electrical Codes, ANSI/NFPA No. 70 latest edition or, in Canada, to the Canadian Electrical Code, Part I, CSA C22.1, latest edition. Installed conduit must not block openings and must allow the side doors to be opened.

3.4.1 The Power Input Junction Box

The main power connections are connected to the over current safety device rated for a 20 Amp 3 phase circuit (for either 208-240 or 480 VAC) and ground terminal located in the main power connection box. This box is located at the lower front left side of the boiler. The power connection has four points of contact: Terminals 1, 3, 5 and G. Connect the three wires supplying the three phase power to terminals 1, 3 and 5. Connect the main boiler ground wire to G.

The internal control transformer may be pre-wired from the factory for operation with 240 VAC. If 208 VAC three phase power is used, the internal control transformer must be wired for operation at this lower voltage. The wire in terminal X3 on the load side of the internal control transformer must be moved to terminal X4. This supplies the 120 VAC power to the controls from the 208 VAC main voltage. Refer to Sections 6.1.4 and 6.1.5 for proper wiring and configuration of the internal control transformer.

CAUTION

Be sure to check the nameplate on the boiler before connecting electrical supply.

NOTICE!

A dedicated earth ground (green wire) is required to avoid nuisance shutdowns. Do not ground through the conduit.

WARNING

The high voltage (TB2) terminal block contains 120 VAC output pilot duty. Do not connect any 120 VAC supply voltage to the high voltage (TB2) terminal block. Connecting a 120 VAC supply voltage to TB2 can result in serious injury or death.

The SC-3000 and SC-4000 boiler may be supplied from the factory as either 208–240 VAC or 440–480 VAC. Refer to Sections 6.1.4 and 6.1.5 for proper wiring and configuration of the internal control transformer.

3.4.2 High Voltage (TB2) Terminal Block

DHW Pump Relay w/ Delay Off – This output is enabled when there is a call for DHW. When the call for heat is removed, the output remains enabled for the post pump time parameter within the DHW settings. This output provides 120 VAC, 0.5 Amp service to TB2-12. The neutral for this circuit is provided on TB2-5.

Circ Pump Relay w/ Delay Off – This output is enabled when there is a call for heat. When the call for heat is removed, the output remains enabled for the post pump time parameter within the CH settings. This output provides 120 VAC, 0.5 Amp service to TB2-13. The neutral for this circuit is provided on TB2-6.

Damper Relay – This output is enabled when the call for heat is enabled. This output provides 120 VAC service to TB2-14. The neutral for this circuit is provided on TB2-7. This circuit is for pilot duty only.

Master Alarm Relay – This is a dry set of contacts that are normally open and will close in the event of an alarm output from the boiler control, connecting TB2-15 and TB2-16.

Flame Detected Relay – This is a dry set of contacts that are normally open and will close whenever the boiler control is reading a flame, connecting TB2-17 and TB2-18.

Refer to sections 6.1.4, 6.1.5 and 6.2.2 for proper wiring and configuration of the electrical connections.

3.4.3 Low Voltage (TB1) Terminal Block

Enable/Disable – TB1-1 and TB1-2 are used for enabling the boiler (factory installed jumper). Closing this circuit allows the boiler to run. Opening this circuit prevents the boiler from running. This circuit is energized by the boiler. It has a 24 VAC potential. Devices connected to these terminals must be rated for 24 VAC **Note: This circuit will be changed by certain CH modes and Cascade Master Modes.** * Note 1

External Interlock – TB1-3 and TB1-4 are used for attachment of an additional field safety device to the boiler control circuit (factory installed jumper). Closing this circuit allows the boiler to run. Opening this circuit prevents the boiler from running. This circuit is energized by the boiler with a 5V potential. Devices connected to these terminals must be rated for 5V.

Outdoor Temp Sensor – TB1-5 and TB1-6 are connected to the outdoor temperature sensor. The temperature control must be programmed to run an outdoor air schedule. The outdoor air sensor and programming help are available from the local Harsco Industrial, Patterson-Kelley Representative. This circuit is energized by the boiler with a 5V potential. The temperature sensor must be a NTC having 12k @ 77°F.

DHW Stat/Sensor – TB1-7 and TB1-8 are connected to the DHW temperature sensor or thermostat. This circuit is energized by the boiler with a 5V potential. The temperature sensor must be a NTC having 12k @ 77°F.

Header Temp Sensor – TB1-9 and TB1-10 are connected to the header temperature sensor. This circuit is energized by the boiler with a 5V potential. The temperature sensor must be a NTC having 12k @ 77°F.

DHW Flow Switch – TB1-11 is energized by the boiler with a 5V potential. This circuit connects through a flow switch on the domestic side of a domestic hot water system. The flow switch should close upon flow to provide a closed circuit back to TB1-12.

Analog Input – Remote signal for controlling the boiler. The boiler can be operated in a remote setpoint or a remote firing rate control mode. Input 0-10 VDC+ signal on TB1-13 only. The 0 VDC- Analog Input is provided on TB1-14. The temperature control must be programmed to run with the analog input. * Note 1

MODBUS® – TB1-17 and TB1-18 are used for connecting a MODBUS® building management system. *Note 1

Cascade – TB1-19 and TB1-20 are used to connect between boilers that are part of a Master/Member Network. Up to 24 boilers may be connected together. * Note 1

*NOTE 1 - Refer to ENVI® Control Advanced Users Guide (Part # 1004905953) for more information.

3.5 INLET AIR AND EXHAUST VENTING

3.5.1 Applicable Codes and Standards

CODES

United States:

NFPA 54/ANSI Z223.1	National Fuel Gas Code
NFPA/ANSI 211	Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances

Canada:

CAN/CSA B149.1	Installation Codes for Gas Burning Equipment
----------------	--

STANDARDS

UL 1738	Venting Systems for Gas-Burning Appliances, Categories II, III, and IV
ULC S636-95	Standard for Type BH Venting Systems
	Sheet Metal and Thermoplastic Duct Construction Manual Air Conditioning Contractors National Association (SMACNA)

These codes and standards contain information for the venting of gas fired appliances, including, but not limited to vent sizing, location, clearance to combustibles, and safe installation practices. The installation must comply with both the above Federal Codes and with state, provincial and local codes.

WARNING

Design and installation of venting systems should be done only by qualified and knowledgeable venting systems personnel and in accordance with vent system manufacturer's installation instructions. Installing a boiler or vent system using improper installation methods or materials can result in serious injury or death due to fire or asphyxiation.

WARNING

Before connecting a boiler to a venting system, it must be determined whether the boiler is to be installed in a conventional or direct vent configuration. In the US, provisions for combustion and ventilation air must be in accordance with NFPA 54/ANSI Z223.1, National Fuel Gas Code, latest edition, or applicable provisions of the local building codes. In Canada, combustion and ventilation air openings shall comply with CAN/CSA B-149.1 Natural Gas and Propane Installation Code.

WARNING

For correct installation of vent system, read all of these instructions and refer to vent manufacturer's instructions.

Failure to use a proper vent system (types and materials), as described in this manual will void the boiler warranty and may result in rapid deterioration of the venting system, creating a health or life safety hazard.


Faulty vent installation can allow toxic fumes to be released into living areas. This may cause property damage, serious bodily injury or death.

Table 3.5.1
Required Stainless Steel Vent Adapters and Category II Motorized Dampers

Boiler Size	Nom. vent Size	Stainless Vent Adapter	Vent adapter size	Boiler Combustion Air inlet	Combustion air N.C. Motorized Damper	Length
SC-3000	10"	2640000133	10"	12"	1004906946	12"
SC-4000	10"	2640000133	10"	12"	1004906989	14"

This table is for information only. Combustion air dampers and vent adapters are listed for use of design and may or may not be specific to your application.

The optional, but required for Category II venting, normally-closed motorized combustion air damper operates on 120 VAC and features an end limit switch wired into the boiler's external interlock circuit. Upon a call for heat, the boiler's combustion air damper relay will energize and drive the damper open. Once the damper reaches the fully-open position, the end limit switch makes contact and closes the external interlock circuit allowing the boiler to fire. The diagram below shows the wiring necessary to install the normally-closed motorized damper.



3.5.1.1 Gas Vent Categories

Several codes and standards have categorized appliances in accordance with the flue gas temperature and pressure produced by the appliance. The applicable categories are defined as follows:

- **Category II:** An appliance that operates with a non-positive vent static pressure and with a vent temperature that may cause excessive condensate production in the vent.
- **Category IV:** An appliance that operates with a positive vent static pressure and with a vent temperature that may cause excessive condensate production in the vent.
- **Direct Vent:** An appliance that is constructed and installed so that all air for combustion is derived directly from outdoors and all flue gases are discharged to the outdoors.

3.5.1.2 Venting Materials for Flue/Exhaust Systems

The P-K SONIC™ boilers are dual certified as a Category II and Category IV appliances, which vents with a temperature that is likely to cause condensation in the vent. Therefore, any venting system used with the P-K SONIC™ boiler must comply with the requirements for either Category II or Category IV venting systems as specified in the latest edition of NFPA 54/ANSI Z223.1 in the US or the latest edition of CAN/CSA B-149.1 in Canada.

CPVC Venting

US: CPVC pipe conforming to ASTM F441. Sch 80 fittings conforming to ASTM F439. Joints are to be sealed with solvent conforming ASTM 493.

Canada: CPVC Pipe, Fitting and Sealant listed and labeled to ULC S-636 Standard for Type BH Venting Systems.

Polypropylene Venting

US and Canada: Polypropylene such as InnoFlue from Centrotherm or PolyPro from DuraVent or other listed manufacturers. When used, the same manufacturer's material must be used throughout the system. It is not permissible to use material from different manufacturers within the same system.

As per ANSI Z21.13b-2012 * CSA 4.9b-2012:

- **The use of cellular core PVC, CPVC and Radel as venting materials is prohibited.**
- **The use of external insulation on plastic vent pipe is prohibited.**

Acceptable Venting Materials

Table 3.5.1.2

Model	Country	AL29-4C	316L SS	PVC	CPVC	POLYPROPYLENE
SC-3000	US	Yes	Yes	No	Yes	Note 2
SC-4000	US	Yes	Yes	No	Yes	Note 2
SC-3000	Canada	Yes	Yes	No	Note 1	Note 1
SC-4000	Canada	Yes	Yes	No	Note 1	Note 1

Note 1: When this material is used for venting, it must be listed to ULC-S636.

Note 2: When this material is used for venting, it must be listed to UL-1738.

3.5.2 Combustion Air Materials and Sizes

The air intake duct can be fabricated from PVC, CPVC, single wall galvanized steel, or other suitable materials. The duct must be rigid enough to maintain the full required cross sectional area under all operating conditions. Proper sealing of the intake ductwork is necessary to prevent infiltration of air from conditioned space. Joints in PVC or CPVC must be cemented. For galvanized duct, wrap each joint and seam with adhesive aluminum tape or other sealant. The installation of a bird screen on the intake termination is recommended. Ensure that the screen does not become blocked with snow, ice, insects etc. Combustion air duct should be designed with maximum 0.22" wc friction loss.

Combustion air must be free from dust, lint, etc. The presence of such materials in the air supplied to the burner could cause nuisance "Low Air" shutdowns or premature burner failure. The boiler should not be operated during construction while the possibility of drywall dust, demolition dust, etc. exists.

The combustion air supply must be completely free of chemical fumes which may be corrosive when burned in the boiler. Common chemicals which must be avoided are fluorocarbons and other halogenated compounds, most commonly present as refrigerants or solvents, such as Freon, trichloroethylene, perchloroethylene, chlorine, etc. These chemicals, when burned, form acids which quickly attack the boiler and the boiler stack. The result is improper combustion and premature boiler failure.

Acceptable Materials for Venting Systems

Manufactured Venting Systems

US and Canada:

AL29-4C Stainless Steel Vent Systems listed and labeled to UL1738 Venting Systems for Gas-Burning Appliances, Categories II, III, and IV

316L Stainless Steel where certified and warranted by the vent manufacturer for venting of Category II, III, or IV appliances

WARNING

The venting materials listed are intended for the venting of gas burning appliances only. Do not use these venting materials for venting liquid or solid fuel (such as oil, kerosene, wood or coal) appliances.

Maintain clearances to combustibles as listed in the vent manufacturer's installation instructions or as set forth in the codes and standards listed in this section.

Do not use these vent pipes for incinerators of any sort.

This boiler is not certified for use with PVC venting. Use of PVC venting may result in vent failure and possible serious injury or death.

Table 3.5.3

P-K SONIC™ Boiler Model	Required SCFM
SC-3000	629
SC-4000	839

3.5.2.1 Air Inlet Requirements — United States (NFPA 54/ANSI Z223.1 & NFPA/ANSI 211)

⚠ WARNING

Under no circumstances shall the boiler room ever be under a negative pressure. Particular care should be taken when exhaust fans, compressors, air-handling units or other equipment may rob air from the boiler. Note that this equipment might be in rooms other than the boiler room. This applies to both sealed combustion and atmospheric room combustion air applications.

NOTE:

1. The required size of openings for combustion and ventilation air shall be based on the net free area of the opening.
2. Screens shall be not smaller than ¼"
3. Motorized louvers shall be interlocked with the appliance so that they are proven open prior to main burner ignition and operation.

When air is supplied from inside the building, the total required volume shall be the sum of the required volume for all the appliances located in the mechanical room. Adjacent rooms furnished with fixed openings communicating directly with the mechanical room are considered part of the required volume. The minimum volume is 50 ft³ per 1000 Btu/hr (4.8 m³/kW) of installed appliance input capacity.

Openings used to connect indoor spaces to obtain the required minimum volume shall be sized as follows:

- When rooms are on the same floor, each opening shall have an area equal to 1 square inch for each 1000 Btu/hr (2200 mm²/kW) of installed appliance input capacity, but not less than 100 square inches. One opening should commence less than 12 inches above the floor and the other less than 12 inches below the ceiling. The minimum dimension of air openings shall be 3 inches.
- When rooms are on different floors, each opening shall have an area equal to 2 square inches for each 1000 Btu/hr (4400 mm²/kW) of installed appliance input capacity.

When combustion air is supplied from outside the building, the boiler room shall be provided with one or two openings to ensure adequate combustion air and proper ventilation.

When using one permanent opening, the opening shall commence within 12 inches of the ceiling and shall communicate directly with the outdoors or through a vertical or horizontal duct that communicates to the outdoors.

Minimum free area of the opening is 1 square inch for each 3000 Btu/hr (700 mm²/kW) of installed appliance input capacity, and not less than the sum of the areas of all vent connectors in the room.

When using two permanent openings, one opening shall commence within 12 inches above the floor and the other within 12 inches below the ceiling, preferably on opposite walls. The openings shall communicate directly, or by way of ducts, with free outdoor air. The minimum net free area of the openings shall be calculated in accordance with the following:

- When air is taken directly from outside the building, each opening (minimum of two, as outlined above), 1 square inch for each 4,000 Btu per hour (550 mm²/kW) of total boiler input is required.
- When air is taken from the outdoors through a vertical duct into the mechanical room, 1 square inch per 4,000 Btu per hour (550 mm²/kW) of total boiler input is required.
- When air is taken from the outdoors through a horizontal duct into the mechanical room, 1 square inch per 2,000 Btu per hour (1100 mm²/kW) of total boiler input is required.

US Minimum area of ventilation openings per boiler (sq inches) Table 3.5.2.1

P-K SONIC™ Boiler Model	AIR SOURCE					
	INDOOR AIR SUPPLY		OUTDOOR AIR SUPPLY			
	SAME FLOOR	DIFF FLOORS	ONE OPENING	TWO OPENINGS		
DIRECT				VERT DUCT	HORIZ DUCT	
SC-3000	3000	6000	1000	750	750	1500
SC-4000	4000	8000	1334	1000	1000	2000

3.5.2.2 Air Inlet Requirements – Canada (CAN/CSA B149.1)

A. Ventilation of the space occupied by fuel burning appliance(s) or equipment shall be supplied by a ventilation opening at the highest practicable point communicating with the outdoors. The total cross sectional area of the ventilation opening must be either 10% of the net free area required for combustion air or 10 sq. in. (6500 mm²), whichever is greater.

B. Use the following opening calculation for P-K SONIC™, MACH® or MODU-FIRE® FD boilers:

When combustion air is supplied for a forced draft burner by natural airflow from the outdoors and there is no draft regulator or draft hood in the same space, there shall be a permanent opening with a cross sectional area not less than 1 sq. in./30,000 Btu/Hr (70 mm²/kW) of the total rated input to the burner(s). This opening must not interfere with the ventilation air opening defined in paragraph A.

C. Use the following opening calculation for P-K THERMIFIC® boilers or other natural draft or fan-assist appliances:

When combustion air is supplied for natural or fan-assisted burners by natural airflow from the outdoors, there shall be a permanent opening with a cross sectional area not less than 1 sq. in./7000 Btu/Hr (321 mm²/kW) up to and including 1,000,000 Btu/Hr plus 1 sq. in./14,000 Btu/Hr (155 mm²/kW) in excess 1,000,000 Btu/Hr. This opening must be either located at or ducted to a point not more than 18 in. (450 mm) or less than 6 in. (150 mm) above floor level. This opening is in addition to the ventilation air opening defined in paragraph A.

D. When combustion air is supplied by natural airflow into a space containing both types of appliance described in paragraphs B and C, the cross sectional area of the opening shall be not less than the sum of the cross sectional areas for all appliances in the space as calculated by the applicable method. This opening is in addition to the ventilation air opening defined in paragraph A.

E. When a duct is used to meet the requirement for combustion air supply, as described in paragraphs A through D, above, the opening of the duct shall be located so there is no possibility of cold air affecting steam or water piping, electrical equipment or mechanical equipment.

F. When combustion air is supplied by mechanical means, an airflow-sensing device must be installed. It must be wired into the pre-ignition limit string to prevent the burner from starting or to stop an operating burner in case of air supply failure.

G. When all combustion air is supplied through a make-up air heater, and the appliance is interlocked to the heater, the requirements of paragraphs A through F do not apply.

Canadian Minimum Area of Combustion and Ventilation Air Openings Table 3.5.2.2

P-K SONIC™ Boiler		Required Combustion Air Opening		Ventilation Air Opening	
Model	Input (Btu/Hr)	in ²	mm ²	in ²	mm ²
SC-3000	3,000,000	100	64,516	10	6,452
SC-4000	4,000,000	134	86,451	13.4	8,645

3.5.3 Flue Venting

This boiler is not certified for use with Type "B" vent nor with PVC venting.

P-K SONIC™ boilers are dual certified as a Category II and Category IV appliances, as defined in ANSI Z21.13/CSA 4.9, latest edition. The vent material must be as listed in the Table of Acceptable Materials for Venting Systems in Section 3.5.1.2 above. The exhaust vent can be run horizontally or vertically.

Vent installations shall be in accordance with NFPA54/ANSI Z223.1, the National Fuel Gas Code, or CAN/CSA-B149.1, the Natural Gas and Propane Installation Code, or applicable provisions of the local building codes.

3.5.3.1 Vent Sizing

The vent must be sized in accordance with the ASHRAE Systems and Equipment handbook, Chapter 30 or according to the vent manufacturer's recommendations. When using manufactured venting systems, consult your vent supplier for correct sizing and structural support requirements.

Vent Design Parameters Table 3.5.3.1

P-K SONIC™ Boiler Model	Frictional Resistance	Stack Temperature	CO2 Natural Gas	CO2 LP Gas
SC-3000/SC-4000	0.22" wc	220 °F	9.2%	10.4%

NOTE:

1. The free area of a combustion air supply opening is calculated by deducting the blockage area of any fixed louvers, grilles or screens from the total area of the opening.
2. Screens shall be not smaller than ¼"
3. Motorized louvers shall be interlocked with the appliance so that they are proven open prior to main burner ignition and operation.

WARNING

Do not locate intake or exhaust terminations directly above a walkway; dripping of condensation can cause icing of the walking surface. Maintain a minimum clearance of 6 ft (1.83 m) horizontally from any electric or gas meter, regulator or relief equipment.

NOTICE!

Make sure that the weight of the vent is **not supported** by the boiler vent collar. **The collar is not designed to support the weight of the vent.** Horizontal vent sections shall be supported in a manner to prevent sags or low spots where condensate can collect. Structural supports must be connected to building elements of sufficient strength to withstand the weight of the vent system and any bending forces imposed by the venting system.

3.5.3.2 Required Clearances

Conventional Vent Systems Clearances

The following termination clearance requirements are for conventional, non-direct vent installations:

- The vent system shall terminate at least 3 ft above a forced air inlet within 10 feet horizontally.
- The vent system shall terminate at least 4 ft below, 4 ft horizontally from or 1 ft above any door, operable window or gravity inlet into any building. The bottom of the vent terminal shall be at least 12 in. above grade or highest expected snow line (if applicable).
- Through the wall terminations shall not terminate over public walkways or over an area where condensate or vapor could create a nuisance or hazard or could be detrimental to the operation of regulators, relief valves or other equipment.

Direct Vent (Sealed Combustion) Systems Clearances

- The vent terminal shall be located at least 12 in. from any air opening into a building. The bottom of the vent terminal shall be at least 12 in. above grade. Both the vent and air intake terminals must be at least 12 in. above the highest expected snow line.
- Through the wall terminations shall not terminate over public walkways or over an area where condensate or vapor could create a nuisance or hazard or could be detrimental to the operation of regulators, relief valves or other equipment.
- When multiple direct vent appliances are adjacent, the exhaust must terminate at least 10 feet horizontally or three feet vertically from the air intake of another appliance.

Interior Component Clearances

All vent system components shall be installed so as to maintain the following required minimum clearances:

Table 3.5.3.2

	Combustible	Non-Combustibles
Unlisted single wall metal pipe	Do NOT Use	Do NOT Use
Single wall PVC pipe	Do NOT Use	Do NOT Use
UL 1738 listed Category IV vent	Per manufacturer's listing	Per manufacturer's listing





Figure 3.5.3.2

Reference: NFPA 54/ANSI Z223.1 National Fuel Gas Code

3.5.3.3 Flue Connection

Figure 3.5.3.3



The complete exhaust with drain system is shown in the figure. The boiler connector (provided) is designed to accept a 10" OD nominal pipe. This connector incorporates provisions to drain condensate formed in the vent system using a 3/4" OD drain stub. This drain stub should be connected with the condensate drain on the boiler. The condensate drains shall have a 4" tall trap to prevent the passage of flue gases through the condensate system.

The connection from the boiler to the vent should be as direct as possible and the upward slope of any horizontal breaching should be at least 1/4 inch per linear foot.

3.5.3.4 Vent Termination

The vent shall extend at least three (3) feet above the roof, or at least two (2) feet above the highest part of any structure within ten (10) feet of the vent. This is illustrated in the following diagram.

Additionally the boiler vent shall terminate at least 3 ft above a forced air inlet located within 10 ft.

To prevent the possible re-circulation of flue gases, the vent designer must take into consideration such things as prevailing winds, eddy zones, building configurations, etc. **Harsco Industrial, Patterson-Kelley cannot be responsible for the effects such adverse conditions may have on the operation of the boilers.** Dimensions listed above are minimums and may not be sufficient for conditions at a specific job site.

Vertical vents are allowed to be terminated with a variety of ends, including plain straight pipe, elbow or vent tee. Horizontal vents must be terminated as illustrated in section 3.5.5. A birdscreen with 1" x 1" openings is recommended for the termination. Harsco Industrial, Patterson-Kelley does not recommend using a vent rain cap of any type.

3.5.4 Venting for Multiple Boilers

While the vent design parameters outlined in Section 3.5.3 still apply, achieving those same parameters in a combined vent system, adds a significant degree of complexity. Therefore, venting systems for multiple boilers shall be designed by experienced and knowledgeable venting professionals. The venting system shall be

WARNING

The boiler vent should not be connected into any portion of another mechanical draft system without consulting the vent manufacturer. The boiler shall not be connected to any part of a vent system serving a Category I appliance, nor shall a Category I appliance be connected to any part of the vent system serving this appliance. For CAT II common venting refer to local venting codes. Improper interconnection of venting systems may result in leakage of flue gases into occupied spaces.

NOTE!

The condensate formed from combustion flue gases is acidic. The condensate shall be drained in accordance with local code requirements. A condensate neutralizer may be required by local code.

Figure 3.5.3.4




FIGURE 12.6.2.1 Typical Termination Locations for Chimneys and Single-Wall Metal Pipes Serving Residential-Type and Low-Heat Appliances.

designed to prevent backflow of exhaust gas through idle boilers. For combined breeching installations, please follow recommendations of a qualified venting engineer/manufacturer.

It is recommended that if using common venting the common vent should be designed for maximum continuous pressure of -.04" wc with sizing equal throughout the run, and Tee's be used on the outlet of the boilers with locking dampers on the exhaust directly off the boilers and combustion air dampers on the combustion air inlets.

3.5.5 Sealed Combustion/Direct Vent Systems

These boilers are also certified for operation with a sealed combustion air and pressurized venting system. Such a system employs a sealed combustion air intake duct leading from outdoors and a sealed exhaust vent terminating outdoors. Air flow through the system is maintained by the combustion air fan. Allowable configurations of vent and air intake terminations are illustrated to the right. Note, drains have been omitted for clarity.

The combined pressure drop of the air supply duct and exhaust vent must not exceed 0.44" wc This pressure drop includes both the inlet and exhaust duct friction loss. Note - the inlet air duct loss should not exceed 0.22" wc.

Both the air inlet if used and the exhaust vent must terminate on the same wall of the building and must utilize the same type of termination fitting. Allowable termination fittings are: 90° elbows or tees.

This boiler may be installed with sidewall vent using room air. (Refer to air inlet requirements Section 3.5.2.1)

Figure 3.5.5




Figure 3.5.5 shows the sidewall penetration requirements. The exhaust vent must be at least 3 feet above the air intake. The air intake and exhaust vent must extend 6" to 12" from the exterior wall and be offset.

3.5.5.1 Inlet Duct Connection to Boiler

Connect the air supply duct to the inlet air collar on the boiler. The air inlet collar is 11.875" OD. Fasten the air inlet duct to the collar with sheet metal screws at 90° angles and seal with aluminum tape or sealant.

3.5.5.2 Intake Duct Materials and Sizes

The air intake duct can be fabricated from PVC, CPVC, single wall galvanized steel, or other suitable materials. The duct must be rigid enough to maintain the full required cross sectional area under all operating conditions. Proper sealing of the intake ductwork is necessary to prevent infiltration of air from conditioned space. Joints in PVC or CPVC must be cemented. For galvanized duct, wrap each joint and seam with adhesive aluminum tape or other sealant. The installation of a birdscreen on the intake termination is recommended. Ensure that the screen does not become blocked with snow, ice, insects etc.

Air Requirements – SCFM

Boiler MODEL	Required SCFM
SC-3000	629
SC-4000	839

Table 3.5.5.2

3.5.6 Removing an Existing Boiler

When an existing boiler is removed from a common venting system, the common venting system is likely to be too large for proper venting of the appliances remaining connected to it.

At the time of removal of an existing boiler, while the other appliances remaining connected to the common venting system are not in operation, the following steps should be followed with each appliance remaining connected to the common venting system placed in operation:

1. Seal any unused openings in the common venting system.
2. Visually inspect the venting system for proper size and horizontal pitch and determine that there is no blockage or restriction, leakage, corrosion or other deficiency which could cause an unsafe condition.
3. Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances

remaining connected to the common venting system are located and other spaces of the building. Turn on clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.

4. Place the appliance being inspected in operation. Follow the lighting instructions. Adjust the thermostat so that the appliance will operate continuously.
5. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle or smoke from a cigarette, cigar or pipe.
6. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous conditions of use.

Any improper operation of the common venting system should be corrected so the installation conforms to the National Fuel Gas Code, ANSI Z223.1 and CSA B149 Installation Code. When resizing any portion of the common venting system, the common vent system should be resized to approach the minimum size as determined using the appropriate tables in part 11 of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or CAN/CSA B149.1 Natural Gas and Propane Installation Code.

3.6 GAS PIPING

Before making the gas hook-up, make sure the boiler is being supplied with the type of fuel shown on the boiler nameplate.

The boiler shall be installed such that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)

The boiler is factory fire-tested and adjusted for proper combustion. The gas train components are certified to handle a maximum inlet pressure of 14" wc (1/2 psig). Typical gas pressure supply for natural gas is 7" wc (11" wc for propane). If the available gas pressure exceeds 14" wc, a suitable additional intermediate gas pressure regulator of the "lock up" type must be provided to reduce the pressure to less than 14" wc. Refer to boiler label for minimum inlet gas pressure.

WARNING

All threaded connections must be made using a pipe compound that is resistant to the action of liquefied petroleum gases. Do not use Teflon tape on gas line threads.

NOTICE!

See Pipe Capacity for Natural Gas chart on the following page for required pipe size, based on overall length of pipe from meter plus equivalent length of all fittings. Approximate sizing may be based on 1 cubic foot of natural gas per 1,000 Btu per hour input, i.e., 3,000,000 Btu per hour requires about 3,000 cubic feet per hour. (See "Typical Boiler Operating Conditions," Section 4.4 for more information.)

RECOMMENDED GAS PIPING INSTALLATION




Figure 3.6

Install a sediment trap (drip leg) and a union connection ahead of the primary manual shutoff valve on the boiler. A gas piping schematic is shown below. Gas piping should be installed in accordance with National Fuel Gas Code, ANSI Z223.1, latest edition, and any other local codes which may apply; in Canada see CAN/CSA-B.149.1, latest edition. In the Commonwealth of Massachusetts, the gas cock must be a "T-handle type."

Pipe Capacity for Natural Gas Table 3.6

Nominal Iron Pipe Size (Inches)	Internal Diameter (Inches)	Equivalent Pipe Length		Maximum Capacity in Cubic Feet of Natural Gas Per Hour Pressure Drop of 0.5 inch Water Column/Equivalent Length of Pipe (in feet)						
		90° Ell (Feet)	Tee (Feet)	20	40	60	80	100	150	200
2.5	2.469	6.16	12.3	4350	3000	2400	-	-	-	-
3	3.068	7.67	15.3	7700	5300	4300	3700	-	-	-
4	4.026	10.1	20.2	15800	10900	8800	7500	6700	5500	4600

NOTICE!

The SC-3000 - SC-4000 boiler is furnished with 4" grooved connections and Victaulic Style 75 Couplings. These couplings must be used with the EPDM Victaulic seals. Isolating valves must be installed in both water connections.

NOTICE!

Condensate Trap must be piped to drain in accordance with all national, state and local codes. If installed outdoors and the local climate requires freeze protection, it must be field heat traced.

3.6.1 Gas Supply Piping by Installer

The boiler and all gas piping connections should be pressure-tested and must be checked for leaks before being placed into service. Test with compressed air or inert gas if possible.

The boiler must be **disconnected** at the boiler manual shut-off valve (located at the end of the supplied gas train) from the gas supply piping system during any pressure testing of the system at pressures in excess of 1/2 psig (14" wc).

During any pressure testing of the gas supply piping system at pressures equal to or less than 1/2 psig (14" wc), the boiler must be isolated from the gas supply piping system by closing the manual shut-off.

Some leak test solutions, including soap and water, may cause corrosion. These solutions should be rinsed-off with water after testing.

3.7 BOILER WATER PIPING

3.7.1.1 Piping with Refrigeration Lines

When installed in a two-pipe system that provides both chilled and hot water, the control system should be configured so as to limit the time rate of change of temperature at the boiler. Consult your authorized Harsco Industrial, Patterson-Kelley boiler representative for application guidance.

3.7.1.2 Piping with Air Handling Units

The boiler piping system of a hot water heating boiler connected to heating coils located in air handling units, where they may be exposed to refrigerated air circulation, must be equipped with flow control valves or other automatic means to prevent gravity circulation of the boiler water during the cooling cycle.

3.7.2 Boiler Inlet and Outlet Connections

All water connections should be in compliance with national, state and local code requirements. Adapters from Victaulic to NPT are available from Harsco Industrial, Patterson-Kelley.

The bottom rear connection to the boiler is the INLET and must be used for the return from the system.

The top rear connection to the boiler is the OUTLET and must be connected as the supply to the system.

Piping must be installed such that no piping stresses are transmitted to the boiler. The boiler shall not be used as a pipe anchor.




Figure 3.7.2

3.7.3 Boiler Water Piping by Installer

Strainer

To avoid possible contamination of the boiler with dirt, rust or sediment from the system, a strainer near the boiler inlet is strongly recommended. Even new systems may contain sufficient foreign material to eventually reduce the performance of the heat exchanger. Adequate circulation of good clean water is essential for maximum efficiency and long life of the boiler.

Relief Valve Piping

Each boiler is supplied with a pressure-relief valves sized in accordance with ASME requirements. The relief valves must be piped to an acceptable drain. Reducing couplings or other restrictions are not permitted in the discharge line. The Section IV valve must be installed as per Fig 3.7.2 and the Section VIII valve must be installed according to ASME/local codes. Both valves are provided with the boiler for convenience.

Low Water Cut-off

The boiler is furnished with a probe-type low water cut-off; no field piping is required. If the water level in the boiler drops below the probe, the boiler will shut down and LOCKOUT LOW WATER LEVEL will be displayed on the control panel. The low water cutoff circuit will automatically reset when the low water condition clears; however the boiler controls will retain the lockout condition until the reset button on the display is depressed. Installation of external limit controls may be required by certain codes or in certain installations. Review applicable local codes for details.

Drain Valve and Piping

A drain valve is factory installed in the boiler inlet (system return) piping. Prior to draining the boiler, electrical power and gas supply must be turned off to the boiler, and the boiler must be isolated from the system at the supply and return connections.

Condensate Drain

The condensate is acidic (pH between 3.0 and 5.0) and may be corrosive to some building drain systems. A condensate neutralization system may be required and is available from Harsco Industrial, Patterson-Kelley. If the condensate drainage system is exposed to freezing temperatures, it must be field heat traced. The boiler could generate up to one gallon of condensate per 100,000 BTU input. As an example, a SC-3000 boiler at full fire could produce 30 gallons per hour of condensate.

3.7.4 Flushing and Filling

Water Quality

The boiler heat exchanger is made of stainless steel. The heat exchanger requires proper water conditions to remain efficient and function properly. For information, please refer to Hartsco Industrial Patterson Kelley Multi-Metal Systems Water Quality Standards as it appears in Appendix 3 as this applies to the warranty of your heat exchanger.

NOTICE!

The low water cutoff probe only prevents boiler operation when the water level in the boiler is insufficient. It does not detect low water conditions in other parts of the system. Installation of additional low water safety devices to protect the system should be considered.

NOTICE!

This drain valve is factory installed for draining of the boiler water only, not the entire system. Draining of the system through the boiler will result in depositing sediment from the system in the boiler which will result in poor heat transfer characteristics of the boiler and early boiler failure.

NOTICE!

Condensate Trap must be piped to drain in accordance with all national, state and local codes.

NOTICE!

Glycol or other treatment chemicals added to the system must be certified by the chemical manufacturer for use in multi-metal systems that include stainless steel boilers.

NOTICE!

Under no circumstances should petroleum based cleaning or sealing compounds be used in the boiler system.

NOTICE!

Under no circumstances should the hydronic system be flushed while the boiler is attached to the system since the debris or corrosion products could accumulate in the boiler and plug the boiler heat exchanger.

WARNING

Never attempt to operate a boiler that has failed to pass all the safety checks described below.

WARNING

After checking controls by manual adjustment, make sure they are always reset to their proper settings.

NOTICE!

If the expected error code(s) do not appear, call for qualified service.

3.8 PRE-START CHECKLIST

Before attempting to start the boiler, make sure the following items have been completed. Refer to the engineering manual for your model for additional information.

1. Inspect the gas train, blower, ignition electrode and boiler in general to be sure there was no damage during shipment or installation.
2. Flue gas from the boiler is properly vented;
3. Gas connection has been made, pressure tested for leakage and the line purged of air. Make sure all required vents have been installed.
4. Water connections are complete and the boiler and system have been filled and purged of air.
5. The boiler is connected to the correct electrical power source listed on the nameplate, and having a disconnect having adequate overload protection.
6. Combustion air openings are not obstructed in any way and have adequate capacity.

7. The boiler is placed the proper distance from any combustible walls
8. Relief valves have been piped to an acceptable drain at a safe point of discharge.
9. Condensate piping is properly connected.
10. Verify system water quality is within specifications.

3.9 SAFETY CHECKS

The following checks of safety systems must be made before putting the boiler into normal operation.

Before firing the boiler refer to *Section 4* for information on the use of the controls, lighting, and shut-down procedures.

3.9.1 Test of Ignition Safety System

Test the ignition system safety shutdown as follows:

1. Cycle the boiler on by generating a heat request. (The method for this will depend on your boiler configuration.)
2. Place the boiler in operation at the high fire setting BNR TEST MODE HI.
3. Smoothly close the downstream manual isolation valve to reduce the gas flow and cause flame failure.
- 4 The display will show LOCKING FLAME FAILURE indicating a flame failure. The lockout will remain until the control is reset.

After completing this test, turn off the boiler and open the downstream manual isolation valve and turn the boiler back on.

3.9.2 Test of Low Water Cut-out

The boiler is furnished with a probe-type low water cut-out in the outlet nozzle. Test as follows:

Push and hold the red "Push to test" button for at least 5 seconds. A manual lockout reset error displaying LOCKOUT LOW WATER LEVEL on the display panel should occur. The LED indicator on the Low Water cut-off will no longer be illuminated.

Optional Test Method: First turn the boiler off, and then turn the pump off. Isolate the boiler from the system. Drain the water level below the low water cut-off probe. Turn the boiler back on. It should not operate, and a manual lockout reset error displaying LOCKOUT LOW WATER LEVEL on the display panel should occur. The LED indicator on the Low Water cut-off will no longer be illuminated.

Return the system to normal operation by refilling and restarting the boiler and pump.

3.9.3 Test of High-Limit Control

Fire the boiler and test the high limit control as follows:

With the main burner operating, turn down the temperature setting on the "high-limit" thermostat until the main burner shuts off. A manual reset lockout displaying LOCKING HIGH LIMIT on the display panel will occur. The high-limit switch must be manually reset prior to resetting the boiler at the display panel. Readjust the high-limit thermostat to the desired setpoint.

3.9.4 Test of Gas Pressure Switches

Low Gas Pressure Switch

The boiler is furnished with a low gas pressure switch. The operation of this switch must be checked by slowly closing the main gas cock while the burner is operating. The switch should shut down the main burner. When the gas pressure switch opens, a manual reset lockout displaying LOCKING LOW GAS PRESSURE on the display panel will occur. Upon re-opening the main gas cock, the LOCKING LOW GAS PRESSURE will remain on until the display panel is manually reset.

High Gas Pressure Switch

The boiler is furnished with a high pressure switch that must be checked by closing the downstream gas cock with the boiler off. When the boiler is started, it should enter its normal starting cycle and fail on high gas pressure when the automatic gas valves open. The high gas pressure switch actuation is evident when a manual reset lockout displaying LOCKING HIGH GAS PRESSURE on the display panel occurs. Upon re-opening the gas cock, the LOCKING HIGH GAS PRESSURE indicator will remain on until the display panel is manually reset.

3.10 INITIAL ADJUSTMENTS

3.10.1 Operating Temperature Controller

The SC-3000 and SC-4000 boilers are equipped with ENVI® control; an intelligent control system with advanced features such as text-based display, communication capabilities, and boiler sequencing. Errors are date and time stamped providing built-in history of boiler status and performance.




Figure 3.10.1a

CAUTION

The user should become thoroughly familiar with the operation of the boiler and controls before attempting to make any adjustments.

CAUTION

Changing parameters requires an understanding of the parameters and the functionality of the boiler. The boiler may not function properly if parameters are changed from the factory values.

This control constantly tracks the load by recording burner high, low and mid run hours. One control to do it all – temperature control, flame safeguard, firing rate control, blocked flue protection, outdoor air reset, freeze protection, built-in cascade sequencing, MODBUS communication and more.

The boiler control has a text display panel. The display panel is used to setup and monitor boiler operation by means of six push buttons MENU, BACK, ENTER, UP, DOWN, and RESET as shown above. The buttons across the bottom are used to navigate through the various screens. The four line screen shows boiler operating information on various screens. The display screen is back lit for ease of viewing. Pressing any key will illuminate the back light.

*NOTE 1 - Refer to ENVI® Control Advanced Users Guide (Part # 1004905953) for more information.

Operating Temperature Controller, continued

The standby screen is shown upon startup. This screen shows the date, time, boiler status, supply temp and setpoint temp. Pushing the menu button displays a menu of options. The menu includes access to the Standby, Information, Errors, Program Parameters, Configuration, Cascade, and Service Menu. The Up and Down buttons are used to position the arrow next to the desired option and the enter button is pushed to enter that option. The list is displayed and may have more than four lines. Use the down arrow to view the complete list.




Figure 3.10.1b

3.10.2 Boiler Set Point

The factory default setpoint is 180 °F. If a different setpoint is desired, push the menu button and then select PARAMETERS from the menu. A screen opens that allows the user to view and change operating parameters. Select the CH settings to adjust parameters related to the boilers Comfort Heat function.




Figure 3.10.2a




Figure 3.10.2b




Figure 3.10.2c

For example, selecting the Setpoint parameter opens up a screen that allows the setpoint to be changed. The up or down buttons are used to adjust the CH setpoint up or down as desired. The enter button is pushed once the desired temperature is reached.

3.10.3 Other CH Parameters

Additional CH Parameters are available and used for the various CH Modes other than mode 0, the standard Setpoint & (Thermo)Stat control mode. These modes are further described in the ENVI® Control Advanced User's Guide.

Description	Value	Units
CH Setpoint	###	°F
BLR OP (Off = 0, On = 1, Off/Pump On = 2, and On/Pump On = 3)	#	0-3
CH Mode	#	0-8
Hysteresis On (On Differential)	##	°F
Hysteresis Off (Off Differential)	##	°F
Post Pump Time	###	Sec

Table 3.10.3

3.10.4 Other Parameters

Other parameters include the settings for DHW (Domestic Hot Water), Boiler Settings and OEM Settings. Boiler and OEM Settings are used during the initial programming of the control and are not adjustable.

3.10.5 Additional Menu Items

In the main menu, Standby, Information, Errors, Program Parameters, Configuration, Cascade, and Service Menus are available. They are used for various functions of the boiler. These functions are described further in the ENVI® Control Advanced User's Guide.

These menu items will be described briefly here:

- STANDBY is the default screen and is shown during normal boiler operation.
- The INFORMATION menu lists items that the boiler monitors such as temperatures, operating conditions, and status of switches and components.
- The ERRORS menu has information about the boiler status at the time of an error.
- The PARAMETERS menu allows the user to set up selected boiler functions and operating modes.
- The CONFIGURATION menu covers basic display information such as language, units, date/time, etc.
- The CASCADE menu is used to sequence multiple boilers (up to 24 max) in a Master/Member network system. Use of this function is described in detail in the Advanced User's Guide.

3.10.6 Service Menu

Two test modes are available in the service menu.

BNR ON TEST HI LOW

BNR OFF FAN HI LOW

The first test mode allows the service technician to hold the boiler in high or low fire during firing operation so that the combustion adjustment can be performed as indicated below.

The second test mode checks the fan rate with the burner off at high speed or at low speed.

These test modes will automatically terminate after 15 minutes of inactivity or can be terminated from the control/display panel by pressing the cancel/reset button.




Figure 3.10.6a




Figure 3.10.6b

3.11 FUEL/AIR ADJUSTMENT

The SC-3000 and SC-4000 boilers are equipped with a gas/air ratio control valve and a gas safety shut off control valve, combined into one valve assembly. The valve functions in series with the variable speed combustion blower to supply the correct gas air ratio for optimum firing performance and efficiency. The combustion blower speed is controlled automatically by the boiler controller. The blower speed determines the amount of air flow and the amount of suction/negative pressure at the gas valves. The gas valve adjusts gas flow to maintain the proper delivery pressure at the outlet of the valve.

NOTICE!
Adjustments shall only be performed by qualified and knowledgeable installer or service agency specifically trained and certified to perform maintenance and/or startup on the Harsco Industrial, Patterson-Kelley® boiler.

3.11.1 Gas Pressure Adjustment

See rating plate for the minimum and maximum gas pressure of the boiler. The supply pressure during main burner operation must be greater than the minimum indicated on the rating plate. Nominal gas supply pressure is 7" wc for natural gas. The gas pressure must not exceed 14" wc which is the maximum allowable pressure on the gas train components. Each boiler is furnished with a manual shut-off valve which has an integrated test port. This port is located on the upstream side of the valve body for measuring supply pressure. (See Figure 3.10.6b)

The air flow is pre-set at the factory prior to shipment. Gas flow is dependent primarily on fan speed not upstream gas pressure. The automatic gas valve may have to be adjusted to obtain proper combustion readings for specific local conditions. A combustion analyzer must be used. Combustion should be set in accordance with Table 3.11.2.

3.11.2 Combustion Setup and Adjustment

Set the combustion using the Service Menu BNR ON TEST HI & BNR ON TEST LOW modes. These test modes should be used when checking and setting the gas safety shut off/control valves on the SC-3000 or SC-4000 boiler. In this mode a heat request is required. Once the boiler cycles on, use the arrow keys to access the Service Menu and select the BNR ON TEST HI or the BNR ON TEST LOW mode and push enter. The boiler will ramp up to high or low fire.

Table 3.11.2 (PLACE Holder)

Fuel	Nominal Gas Pressure	High Fire Setting		Low Fire Setting	
		% O ₂	% CO ₂	% O ₂	% CO ₂
Natural Gas	7" wc	4.8 ± 0.2	9.2 ± 0.1	5.0 ± 0.2	9.1 ± 0.1
Propane Gas	11" wc	4.8 ± 0.2	10.4 ± 0.3	5.0 ± 0.2	10.3 ± 0.3

To adjust high fire:

Required Tools: Flat head screwdriver and Combustion analyzer

Start the boiler and observe proper operating parameters for the system. Set boiler to the "BNR ON TEST HI", as described above, to achieve maximum firing rate of the boiler. Check combustion readings using the combustion analyzer. If combustion readings are not in accordance with *Table 3.11.2*, adjust as follows: Open the front panel of the boiler. Locate the automatic gas valve. Turn the orifice adjusting screw, located on the downstream side of the valve, in the direction indicated on the sticker to increase or decrease the gas flow. Increasing the gas flow decreases the combustion exhaust O₂, while decreasing the gas flow increases the combustion exhaust O₂. There will be a slight time delay between the adjustment and the response of the CO₂/O₂ measuring instrument. Adjust the settings in small increments and allow the combustion readings to stabilize before readjusting. When desired adjustments are complete, check and adjust low fire if necessary.

To adjust low fire:

Required Tools: 2.5 mm hex wrench and Combustion analyzer

Start the boiler and observe proper operating parameters for the system. Set boiler to the "BNR ON TEST LOW" as described above, to achieve minimum firing rate of the boiler. Check combustion readings using the combustion analyzer. If combustion readings are not in accordance with *Table 3.11.2*, adjust as follows: Open the front panel of the boiler. Locate the automatic gas valve. Turn the offset screw, located in the bottom center of the side of the valve, in the direction indicated on the label to increase or decrease the gas. Increasing the gas decreases the O₂, while decreasing the gas increases the O₂. There will be a slight time delay between the adjustment and the response of the CO₂/O₂ measuring instrument. Adjust the settings in small increments and allow the combustion readings to stabilize before readjusting. When desired adjustments are complete, check and adjust hi fire if necessary.




Figure 3.11.2

3.11.3 Checking Flame Signal

Using the control panel, enter the information mode and scroll down view the flame signal. This shows μA when the boiler is firing and shows 0μA when the boiler is not firing. 7-8μA is a strong flame signal.

4 OPERATION

4.1 GENERAL

4.1.1 Control Panel Front

Become familiar with the basic operation of the boiler. The interior of the front door shows the boiler Operating Instructions.




Figure 4.1.1

4.1.2 Factory Tests

Safe lighting and other performance criteria were met with the gas manifold and control assembly provided on this boiler when the boiler underwent factory tests specified in ANSI Z21.13/CSA 4.9, latest edition. (See "Factory Firetest" label.)

4.2 NORMAL LIGHTING AND SHUT-DOWN PROCEDURES

4.2.1 Lighting Procedures

1. Make sure the system is filled with water and water is circulating in the system. Turn on electrical supply and open the gas supply valves to the boiler.
2. Turn the on/off switch to the on position. If an error is indicated, see Section 5.5 of this manual to troubleshoot the problem and take the necessary corrective action before proceeding.
3. Set the desired high temperature limit and operating temperature. The controller will now complete the automatic firing sequence.

4.2.2 Normal Shut Down Procedures

1. Close all manual gas valves.
2. Turn off electric power.

4.3 EMERGENCY SHUT OFF

In case of emergency, shut off gas at a valve external to the boiler. See diagram at right for valve locations.

WARNING

Do not use this boiler if any part has been under water. Immediately call a qualified service technician to inspect the boiler and to replace any part of the control system and any gas control which has been under water.

WARNING

If overheating occurs or the gas supply fails to shut off, do not turn off or disconnect the electrical supply to the pump. Instead, shut off the gas supply at a location external to the boiler.

NOTICE!

The heat exchanger is constructed and stamped for 160 psig maximum operating pressure and 210°F maximum temperature.

4.4 TYPICAL BOILER OPERATING CONDITIONS

Model Number	Input Rating (BTU/Hr)	Voltage (three phase)	Total Amperage	Gas Flow Rate (CFH)		Output Capacity (Btu/hr)
				Natural Gas (1030 Btu/ft ³)	LP Gas (2500 Btu/ft ³)	
SC-3000	3,000,000	208-240	Less than 20	2913	1200	2,880,000
				440-480	Less than 20	
SC-4000	4,000,000	208-240	Less than 20	3689	1520	3,840,000
				440-480	Less than 20	

Table 4.4




Figure 4.3

⚠ WARNING

Lockout/tagout procedure must be employed when servicing this unit.

⚠ WARNING

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

⚠ WARNING

Use care when reassembling main gas line to assure all connections are tight.

⚠ WARNING

Use care when servicing boiler to prevent the accumulation of gas in or around the combustion chamber.

⚠ WARNING

Determine the cause of any lockout or errors before resetting the boiler. If able to determine cause of lockout, then appropriate corrective action should be taken. If unable to determine cause of the problem, call a qualified service technician. Verify proper operation after servicing.

⚠ WARNING

Check daily to be sure that the boiler area is free and clear of any combustible materials, including flammable vapors and liquids.

5 MAINTENANCE

5.1 MAINTENANCE AND INSPECTION SCHEDULE

This schedule applies when the boiler is in use. Verify proper operation after servicing. Note The blower motor is permanently lubricated and does not require periodic lubrication.

5.1.1 Daily

Observe operating temperature and general conditions. Make sure that the flow of combustion and ventilating air to the boiler is not obstructed. Determine the cause of any service codes or lockouts on the display panel. Observe any unusual noises or operating conditions and make the necessary corrections. Notify responsible individuals for required corrective action or repair.

5.1.2 Weekly

Observe the conditions of the main flame. A normal high fire flame is mostly orange with a blue halo, while at low fire the burner will glow yellowish-orange.

Correct air adjustment is essential to the efficient operation of this boiler. Ensure that the flow of combustion and ventilation air is not obstructed. If an adjustment in the combustion appears necessary, the flue gas composition should be checked with a carbon dioxide (CO₂) or oxygen (O₂) analyzer and compared to the values stated in *Table 3.11.2 of section 3.11.2*. If an adjustment in the combustion is necessary, call a qualified and knowledgeable installer or service agency that has been trained on the Harsco Industrial, Patterson-Kelley boilers.

5.1.3 Monthly

1. Using the control panel, enter the information mode and scroll down view the flame signal. This is measured in micro-amperes of flame conductivity.
2. Test high-limit Control. *Refer to Section 3.9.3.*
3. Test operating temperature controls by reducing or increasing temperature setting as necessary to check burner operation.
4. Test the low water level cut-out. *Refer to Section 3.9.2.*
5. Test low gas pressure switch. *Refer to Section 3.9.4.*
6. Check the condensate drain system. Clean and flush as necessary.

Installation and service must be performed by a qualified and knowledgeable installer or service agency that has been trained on the Harsco Industrial, Patterson-Kelley boilers.

5.1.4 Semi-Annually (required for boilers operated year round)

In addition to the recommended monthly service:

1. Clean burner of any accumulated dust or lint. *See Section 5.2 on "Cleaning the Burner."*
2. Inspect burner for any signs of deterioration or corrosion. Replace immediately if deterioration or corrosion is evident.
3. Check the pH level of the system fluid.
4. Inspect and clean the condensate system and check for leaks. If a condensate neutralization kit is present, open the lid and inspect the limestone rocks. If they are absent or have been significantly worn away, replace them with new limestone rocks. Use high-calcium (or pure) limestone.

5.1.5 Annually

In addition to the recommended monthly and semi-annual service:

1. Inspect and clean the inlet screen of any accumulated dust or lint.
2. Check burner and clean off any soot or foreign material that may have accumulated. *See Section 5.2 on "Cleaning the Burner."* Check for corrosion of the burner and its parts. If there is evidence of deterioration or corrosion, replace immediately. Inspect combustion chamber when the burner is removed for inspection. Note any signs of deterioration. Clean as necessary.
3. Inspect and clean heat exchanger. Remove the various covers to inspect the flue gas passageways. Clean the combustion side casting pins by flushing with clean water and blowing dry with compressed air. Do not use any cleaning agents or solvents. Do not use soap. A soft nylon brush may be used in accessible areas. Be sure to inspect the condensate collection pan that is the lowest part of the heat exchanger.
4. Replace the igniter and gasket.
5. Drain and flush the water side of the heat exchanger as required (separate from system flush) using clean water only.
6. Inspect and clean the condensate system and check for leaks. If a condensate neutralization kit is present, open the lid and inspect the limestone rocks. If they are absent or have been significantly worn away, replace them with new limestone rocks. Use high-calcium (or pure) limestone.
7. Examine the venting system at least once a year. Refer to the vent manufacturer's instructions for requirements in addition to those listed below.
 - a. Check all joints and pipe connections for tightness.
 - b. Check pipe for corrosion or deterioration. If any piping needs replacing, do so immediately.
 - c. Inspect and clean any screens in the vent terminal.
8. Qualified service personnel should thoroughly inspect the heating system and correct any problems prior to re-starting the boiler.
9. Perform combustion analysis and readjust as necessary according to *table 3.11.2 and section 3.11.2*. It is recommended that a copy of this report is filed for future reference.
10. Perform a leak test of the gas valves in accordance with the manufacturer's instructions.

5.2 CLEANING THE BURNER

1. Lockout/tagout gas supply to the boiler.
2. Lockout/tagout electrical power to the boiler.
3. Open the front and side doors of the boiler.
4. Locate the blower and burner transition pieces that are directly in the front of the boiler. *See 6.2.4 for illustration of components.*
5. Remove the 8 nuts and 2 bolts connecting the blower transition piece to the burner transition piece. The blower transition piece is supported and remains in place.
6. Remove the 4 nuts holding the burner transition piece to the studs on the front of the boiler.
7. Pull out the burner transition piece with the 2 gaskets and set aside. Reinstall burner and replace gaskets.
8. Carefully remove the burner and clean with pressurized water.
9. Reassemble being sure to install all gaskets and seals properly.

Installation and service must be performed by a qualified installer or service agency that has been trained on the Harsco Industrial, Patterson-Kelley boiler.

5.3 REMOVING THE HEAT EXCHANGER

⚠ WARNING

Heat Exchanger is heavy and may cause injury if improperly handled. Removal of the heat exchanger should be performed only by knowledgeable and experienced personnel.

5.4 AFTER REPAIRS OR MAINTENANCE

1. Follow "Pre-Start Check List" (*Section 3.8*) and all "Safety Checks" (*Section 3.9*).
2. Check gas pressure. (*Section 3.11.2*). Ensure proper operation of unit.
3. Perform combustion check. Adjust gas flow if necessary. (*Section 3.11.2*).

NOTICE!

Once the boiler begins the ignition sequence, the firing sequence will continue until main flame is reached regardless of heat request. The sequence can be interrupted by turning the power switch off.

WARNING

If any "Manual Reset" limit device trips, DO NOT reset without determining and correcting the cause. Manual Reset Limits include: Flame safeguard, high or low gas pressure, high temperature limit, stack temperature, low water level.

5.5 SEQUENCE OF OPERATION

1. When the Boiler On/Off switch is turned on, power is provided through a circuit breaker to the boiler control and the combustion blower.
2. If the high gas, low gas or low water level control is open, the boiler control locks out and displays an error.
3. When the water temperature is below the boiler control setpoint minus the hysteresis (On Differential), a heat request is generated.
4. Provided all limits are made, the boiler will attempt to start.
5. The controller checks that the air pressure switch is open indicating no airflow. The blower is driven towards the prestart fan speed. When the air pressure switch closes, the 25 second pre-purge time is started. After the pre-purge, the blower is driven to the ignition speed.
6. A trial for ignition begins. The sequence of events is illustrated graphically below.
7. After ignition, the fan may be driven to low fire before the boiler is released to modulation.
8. The control modulates the firing rate between low and high fire to maintain the desired outlet water temperature.
9. The burner will continue firing until the outlet water temperature reaches set point plus hysteresis (Off Differential). At this temperature the fuel supply is shut off and the combustion air fan continues to run for a 30 second post-purge.
10. When the water temperature is reduced by the load on the system, a heat request is generated. The operating sequence will recycle to *Step 4*.




Figure 5.5

5.6 TROUBLESHOOTING

The ENVI® boiler control will display text based error descriptions to indicate any problems with the boiler. There are two types of lockouts the control may experience: manual reset lockouts requiring an operator to press the reset button, and automatic reset lockouts that will self reset when the error condition clears. A listing of errors and their service codes is included at the end of this section.

Should the unit fail to operate, call a qualified service technician to troubleshoot the problem and implement corrective actions.

5.6.1 Loss of Power

In the event of a power failure, the display panel is not illuminated and the entire system is de-energized, closing all automatic valves and halting all boiler operations. When power is restored the sequence of operation will resume at *Step 4*. If any error/lockout is present when the power is lost, the control will retain that error/lockout and display the error/lockout when the power is restored.

5.6.2 Loss of Water Level

The low water switch opens when there is insufficient water level in the boiler. Lockout LOW WATER LEVEL is shown on the display, the burner operation is interrupted, and the boiler locks out. When the correct water level is re-established, and the control reset button is pressed, the boiler will reset and will start the sequence at [Step 4](#).

5.6.3 Low Gas Pressure

The low gas pressure switch opens when there is (or has been) insufficient gas pressure available for proper operation of the boiler. If an external gas-supply shut-off valve is closed for any reason, a low gas condition will result. Locking LOW GAS PRESSURE is shown on the display, the burner operation is interrupted, and the boiler locks out. When proper gas pressure is restored, and the control reset button is pressed, the boiler will reset and will start the sequence at *Step 4*.

5.6.4 High Gas Pressure

The high gas pressure switch opens when there is (or has been) excessive gas pressure for the proper operation of the boiler. Locking HIGH GAS PRESSURE is shown on the display, the burner operation is interrupted, and the boiler locks out. When proper gas pressure is restored, and the control reset button is pressed, the boiler will reset and will start the sequence at *Step 4*.

5.6.5 High Water Temperature

When the boiler water has exceeded both the operating and high-limit temperature the high limit switch opens, and Locking HIGH LIMIT is shown on the display. When the water temperature falls below the high-limit temperature, the boiler will remain locked out until the water high limit switch is manually reset and the front panel reset button is pressed. Once reset, the control will restart the sequence of operation at *Step 4*.

5.6.6 Low Air

If the display panel indicates Locking AIR SWITCH NOT OPEN or Locking AIR SWITCH NOT CLOSED this indicates improper airflow through the boiler. Check the hoses leading to the air switches. Verify proper blower operation. An air switch error does not necessarily mean that the air switch is defective.

When AIR SWITCH NOT OPEN is shown on the display, check that the air switch is open when the fan is off. Check that there is no air flow through the boiler when the fan is off.

When AIR SWITCH NOT CLOSED is shown on the display, check that the air switch is closed when the fan is running. If the air switch does not close within 5 minutes during purge, the boiler locks out. Check that the burner is clean ("Cleaning the Burner," *Section 5.2*) and that there are no obstructions to airflow in the intake or exhaust ducts.

5.6.7 Flame Failure

In the event of a flame failure, the main fuel valves are de-energized and a manual reset lockout occurs. Locking IGNITION FAILURE or Lockout FLAME FAILURE is shown on the display. The cause of flame failure must be diagnosed and repaired before the control is reset.

When IGNITION FAILURE is shown on the display, the boiler did not light during a trial for ignition. Check that the spark, electrode, ignition wire, and gas valve are functioning properly.

When FLAME FAILURE is shown on the display, the boiler lost the flame during run. Check that the combustion is setup properly, the gas pressure is correct, as well as other combustion parameters.

5.6.8 Flame Error

Locking LATE FLAME

Blocking FALSE FLAME

These errors signify flame error. This may be caused by a failed or leaky gas valve or a flame detector malfunction. If gas valve leakage is suspected, the unit must be isolated by turning off the main gas supply line. Qualified and knowledgeable service personnel must be called to evaluate and repair/replace the failed parts.

5.6.9 Stack Problem

BLOCKED FLUE indicates that the high exhaust back pressure switch has tripped. This may be caused by a blocked stack, a blocked air inlet, or a blocked condensate system. When the blockage is removed, the boiler will automatically restart.

5.7 MANUAL RESET ERROR CODES

NOTE: When an Internal Error occurs, as identified above, the failure is internal to the ENVI® boiler control and replacement of the ENVI® control is required. A qualified service technician must replace the control.

Code	ENVI® Display	Lockout	Description
A00	NED	Unassigned	No Error Description, Call For Service
A01	IGNITION FAILURE	Ignition Failure	During an attempt to light, no flame was detected
A02	FLAME FAILURE	Flame Failure	During run, the flame was lost
A03	HIGH LIMIT	High Limit	The temperature in the boiler exceeded the setting on the High Limit Control
A05	INT ERR GAS VLV RLY	Internal Error Gas Valve Relay	Call for service.
A06	INT ERR SAFETY RLY	Internal Error Safety Relay	Call for service.
A07	LOW FLOW / ILK	Low Water Flow or Open Interlock Circuit	Water Flow is Inadequate or Interlock Jumper/Circuit is Open.
A09	INTERNAL ERROR 9 or 27 or 28 or 30	Internal Error 9 or 27 or 28 or 29 or 30	Call for service.
A10	INT ERR E2PROM ERR	Internal Error E2PROM Err	Call for service.
A12	INT ERR E2PROM SIG	Internal Error E2PROM Sig	Call for service.
A13	INTERNAL ERROR 13	Internal Error 13	Call for service.
A14	INTERNAL ERROR 14	Internal Error 14	Call for service.
A15	INTERNAL ERROR 16	Internal Error 16	Call for service.
A16	INTERNAL ERROR 22	Internal Error 22	Call for service.
A18	INTERNAL ERROR 19	Internal Error 19	Call for service.
A19	LATE FLAME	Late Flame	Flame still present after boiler gas valve closed during post purge
A20	EARLY FLAME	Early Flame	Flame detected before boiler gas valve opened during pre purge
A30	HIGH GAS PRESSURE	High Gas Pressure Error	The gas pressure is too high and has tripped the HGPS
A31	LOW GAS PRESSURE	Low Gas Pressure Error	The gas pressure is too low and has tripped the LGPS
A32	INTERNAL ERROR 23	Internal Error 23	Call for service.
A33	FAN WRONG SPEED	Wrong Fan Speed Error	Fan deviation more than 300 rpm for > 1 sec (ignored when fan > 4200 rpm)
A34	AIR SWITCH NOT OPEN	Air Switch Not Open	Air switch does not open when fan is off
A35	AIR SWITCH NOT CLOSE	Air Switch Not Closed	Air switch does not close when fan is running
A37	UV SENSOR DEFECT	UV Sensor Defective	Self Check function of UV detector has indicated a failure
A38	MAX DT EXCEEDED	Max Delta Temp Exceeded	Maximum temperature differential across the boiler has been exceeded
A39	RAPID RISE INLET TMP	Rapid Rise Inlet Error	Inlet temperature is rising too rapidly
A40	RAPID RISE OUT TEMP	Rapid Rise Outlet Error	Outlet temperature is rising too rapidly
A41	RAPID RISE HX TEMP	Rapid Rise HX Temp	Temperature across heat exchanger is rising faster than allowed
A43	LOW WATER LEVEL	Low Water Cutoff	Water is too low for boiler to operate
A45	INTERNAL ERROR 31	Internal Error 31	Call for service.

5.8 AUTO-RESET ERROR CODES

Code	ENVI® Display	Lockout	Description
E01	OUT TEMP SENS OPEN	Outlet Temperature Sensor Open	Boiler outlet water temperature sensor open circuit
E02	IN TEMP SENS OPEN	Inlet Temperature Sensor Open	Boiler inlet water sensor temperature open circuit
E03	FLUE TMP SENS OPEN	Flue Temperature Sensor Open	Boiler flue gas temperature sensor open circuit
E04	DHW TEMP SENS OPEN	DHW Temperature Sensor Open	Domestic Hot Water temperature sensor open circuit
E05	HX TEMP SENS OPEN	Heat Exchanger Temperature Sensor Open	Heat Exchange temperature sensor open circuit
E11	OUT TEMP SENS SHORT	Outlet Temperature Sensor Short	Boiler outlet water temperature sensor short circuit
E12	IN TEMP SENS SHORT	Inlet Temperature Sensor Short	Boiler inlet water temperature sensor short circuit
E13	FLUE TMP SENS SHORT	Flue Temperature Sensor Short	Boiler flue gas temperature sensor short circuit
E14	DHW TEMP SENS SHORT	DHW Temperature Sensor Short	Domestic Hot Water temperature sensor short circuit
E15	HX TEMP SENS SHORT	Heat Exchanger Temperature Sensor Short	Heat Exchange temperature sensor short circuit
E16	HEADER SENS SHORT	Header Temperature Sensor is defective	Header temperature sensor on IF board has a short circuit or an open circuit
E18	LINE NEUTRAL REV	Electrical Error	Hot and Neutral are reversed
E20	FALSE FLAME	False Flame	Flame detected when no flame should be present
E21	LOW FLOW / ILK	Low Water Flow or Open Interlock Circuit	E21 converts to A07 after 5 minutes
E22	NO GROUND 60 HZ ERR	No Ground error	No ground connected or voltage on ground
E23	LINE FREQUENCY ERR	Line Frequency Error	Line frequency deviates from 60Hz by more than 2%
E24	FAULTY GROUND	Faulty Ground	Ground/Earth connection is not functioning correctly
E30	HIGH FLUE TEMP	Flue Gas Temperature Too High	Temperature of the flue gas is greater than setpoint + differential
E32	HIGH INLET TEMP	Inlet Temp Too High	Inlet water is greater than 194°F
E34	BLOCKED FLUE	Blocked Flue	Hi exhaust back pressure switch is tripped due to excess pressure in the flue/stack or excessive negative cabinet pressure
E41	REVERSE FLOW IN OUT	Reversed Water Flow	The water flow through the boiler is reversed (Inlet water is hotter than outlet water)
E42	INTERNAL ERROR 48	Internal Error 48	Call for service.
E46	INTERNAL ERROR 35	Internal Error 35	Call for service.
E47	INTERNAL ERROR 36	Internal Error 36	Call for service.
E48	INTERNAL ERROR 37	Internal Error 37	Call for service.
E49	RAPID RISE HX ERROR	Rapid Rise Heat Exchanger Temperature	Temperature across heat exchanger is rising faster than allowed
E50	RAPID RISE ERROR	Rapid Rise Outlet Temp	Temperature of the Outlet water is rising faster than allowed
E51	INTERNAL ERROR 67	Internal Error 67	Call for Service
E52	WRONG BOILER TYPE	Wrong Boiler Type	Control and Boiler do not match (control is programmed for another type of HarSCO boiler)
E 54	IF COMM FAILURE	Interface Board Failure	No communication with Interface Board

MAINTENANCE

MAINTENANCE

⚠ WARNING

Use of Non-Factory Authorized replacement parts are not recommended for this equipment. All control components are engineered for safety and are designed to work in unison with each of the other components. Use of non-factory authorized replacement parts jeopardizes the functionality of the safety features as well as the performance of the boiler.

6 PARTS/TECHNICAL SUPPORT

Spare parts and replacement parts can be ordered from Harsco Industrial, Patterson-Kelley by calling toll free (877) 728-5351. Reach us by fax at (570) 476-7247.

Refer to the parts list shown on the assembly drawings provided in this manual.

Technical information is also available by calling or visit the Harsco Industrial, Patterson-Kelley website, www.harscopk.com.

When ordering replacement parts please have the model number and serial number of your boiler available.

Typical schematic drawings are shown on the following pages. Drawings specific to your particular boiler can also be supplied by your local Harsco Industrial, Patterson-Kelley representative.

6.1 WIRING DIAGRAMS

6.1.1 Terminal Block Assignments – Power Block

The power block is located in the junction box in the front of the boiler, at the lower left corner. This junction box houses the transformer, the fuses, the power block terminal strip circuit breakers, and the blower relay.

The three space terminal strip circuit breakers are mounted on DIN rail and are for connection of the three power wires. There is an additional space on the DIN rail for a ground connection. This boiler requires 208-240 V, three phase, 60 hz. The boiler requires a dedicated ground wire. Do not ground through the conduit.

6.1.2 Terminal Block Assignments — High Voltage Circuit (TB2)

Terminal Number	Label	Description
3	120V AC Neutral	Neutral for use with TB2-10, Switched Output
4	120V AC Neutral	Neutral for use with TB2-11, 3 Way Valve
5	120V AC Neutral	Neutral for use with TB2-12, DHW Pump Contactor
6	120V AC Neutral	Neutral for use with TB2-13, CIRC Pump Contactor
7	120V AC Neutral	Neutral for use with TB2-14, Damper Output
10	120V AC SW OUTPUT	120V AC output when boiler is switched on (0.5 amp max)
11	120V AC 3 WAY VALVE	120V AC output during CH Mode. 3 way valve is normally closed (not powered) for DHW, and powered open for CH Mode.
12	120V AC DHW PUMP CNTR	120V AC output when boiler is in DHW Mode (pilot duty only)
13	120V AC CIRC PUMP CNTR	120V AC output when boiler is in CH Mode (pilot duty only)
14	120V AC DAMPER RELAY	120V AC output when boiler is enabled (pilot duty only)
15	MASTER ALARM RELAY	This circuit closes when the boiler is in an alarm state
16	MASTER ALARM RELAY	
17	FLAME DETECTED RELAY	This circuit closes when the boiler is firing
18	FLAME DETECTED RELAY	

6.1.3 Terminal Block Assignments — Low Voltage Circuit (TB1)

Terminal Number	Label	Description
1	ENABLE / DISABLE	Boiler Enable, Contact Closure.
2	ENABLE / DISABLE	DO NOT ENERGIZE.
3	EXTERNAL INTERLOCK	External Limit, Contact Closure.
4	EXTERNAL INTERLOCK	DO NOT ENERGIZE.
5	OUTDOOR TEMP SENSOR	Outdoor temperature sensor
6	OUTDOOR TEMP SENSOR	
7	DHW STAT OR SENSOR	Domestic Hot Water sensor or thermostat
8	DHW STAT OR SENSOR	
9	HEADER TEMP SENSOR	Header temperature sensor
10	HEADER TEMP SENSOR	
11	DHW FLOW SWITCH	Domestic Hot Water flow switch
12	DHW FLOW SWITCH COMMON	DHW flow switch indicates potable water flow/usage
13	0-10V ANALOG INPUT	Variable Input (VDC) for remote control of boiler (+)
14	0V ANALOG INPUT	0V for use with TB1-13 (-)
15	For Future Use	Not Used
16	For Future Use	
17	MODBUS COM 1A	Modbus connection to boiler
18	MODBUS COM 1B	
19	CASCADE A TO A	Cascade connection between boilers
20	CASCADE B TO B	


NOTES:

Revision 6/12/2014 - Pressure Drop vs. Flow Chart updated.

Page left blank intentionally

6.1.4 SC-3000 & SC-4000 Transformer Diagrams

SC-3000/SC-4000: 208 VAC, three phase, 60 hertz:




⚠ WARNING

Before making any electrical connections to the boiler, verify that the transformer is properly configured for either 208V, 220-240V, or 440-480V, three phase, 60 hertz service. Improper configuration of the transformer could result in serious injury or death.


⚠ WARNING

The high voltage (TB2) terminal block is for 120 VAC output loads only. Do not connect any 120 VAC supply voltage to the high voltage (TB2) terminal block. Connecting a 120 VAC supply voltage to TB2 can result in serious injury or death.


SC-3000/SC-4000: 220-240 VAC, three phase, 60 hertz:



SC-4000 Only: 440-480 VAC, three phase, 60 hertz:




6.1.5 SC-3000/SC-4000 Boiler Wiring Diagrams
6.1.5.1 SC-3000/SC-4000 Dual Fuel 240 Volt



IF ANY OF THE ORIGINAL WIRE SUPPLIED WITH THIS BOILER MUST BE REPLACED, IT MUST BE REPLACED WITH THE SAME UL WIRE TYPE.

SC3000-SC40
240 VOLT EBM / I



00 Dual Fuel
ENVI® Control


266000152
REV. 0.0

HARSCO
INDUSTRIAL
Patterson-Kelley
East Stroudsburg, PA 18301
570-476-7261
www.harscopk.com

PARTS/TECHNICAL SUPPORT


PARTS/TECHNICAL SUPPORT

6.1.5.2 SC-3000/SC-4000 Dual Fuel 480 Volt



IF ANY OF THE ORIGINAL WIRE SUPPLIED WITH THIS BOILER MUST BE REPLACED, IT MUST BE REPLACED WITH THE SAME UL WIRE TYPE.

SC3000-SC4000
480 VOLT EBM




4000 Dual Fuel
/ ENVI® Control

2660000151
REV. 0.0

HARSCO


INDUSTRIAL
Patterson-Kelley
East Stroudsburg, PA 18301
570-476-7261
www.harscopk.com

6.1.5.3 SC-3000/SC-4000 240 Volt



IF ANY OF THE ORIGINAL WIRE SUPPLIED WITH THIS BOILER MUST BE REPLACED, IT MUST BE REPLACED WITH THE SAME UL WIRE TYPE.

SC3000 - SC4000
ENVI®




00 / 240 VOLT
Control

2660000150
REV. 0.0


HARSCO
INDUSTRIAL
Patterson-Kelley
East Stroudsburg, PA 18301
570-476-7261
www.harscopk.com

6.1.5.4 SC-3000/SC-4000 480 Volt



IF ANY OF THE ORIGINAL WIRE SUPPLIED WITH THIS BOILER MUST BE REPLACED, IT MUST BE REPLACED WITH THE SAME UL WIRE TYPE.

SC3000 - SC4000
ENVI® C



00 / 480 VOLT
Control


2660000149
REV. 0.0

HARSCO
INDUSTRIAL
Patterson-Kelley
East Stroudsburg, PA 18301
570-476-7261
www.harscopk.com


6.2 BOILER PARTS LIST

6.2.1 Main Assembly

Mark	Description
1	Heat Exchanger
2	Blower/Burner Assembly
3	Base
4 A	Gas train - LP
4 B	Gas Train - Natural Gas
5	Controller
6	Electrical Box
7	Front Door & Control Panel
8	Cabinet




6.2.2 Control Panel



PARTS/TECHNICAL SUPPORT

PARTS/TECHNICAL SUPPORT


6.2.3 SC-3000/SC-4000 Heat Engine



Mark	Description
1	Outlet Water
2	Combustion Chamber
3	Heat Exchanger
4	Outlet Water Connection
5	Condensate Collector
6	Igniter
7	Burner
8	Burner Gasket
9	Burner Hood


6.2.4 SC-3000 Gas Train

Mark	Description
1	Burner
2	Burner Transition Piece
3	Blower
4	Venturi
5	Manual Shutoff Valve
6	Low Gas Pressure Switch
7	High gas Pressure Switch
8	Gas Valve
9	High Gas Pressure Switch



6.2.5 SC-4000 Gas Train

Mark	Description
1	Burner
2	Burner transition
3	Blower
4	Venturi
5	Shutoff Valve
6	Low Gas Pressure Switch
7	High Gas Pressure Switch
8	Gas valve



7 LIMITED WARRANTY

Subject to the terms and conditions herein, Harsco Industrial, Patterson-Kelley, Seller, warrants to the original owner at the original installation site that products manufactured by Seller will be free from defects in materials and workmanship for a period of one (1) year from date of start up (the "Warranty Period"), provided that start up is completed within six months from the date of shipment. The heat exchanger and burner will be warranted for a period of (5) five years from the date of shipment (the "Warranty Period").

REMEDY

The sole remedy of this warranty is expressly limited to the repair or replacement of any part found to be defective under conditions of normal use within the Warranty Period. Installation is not included.

Warranty — The owner must notify the original installer of the Product and Seller (Attention: Harsco Industrial, Patterson-Kelley, 155 Burson Street, East Stroudsburg, PA 18301), in writing, within the Warranty Period, providing a detailed description of all claimed defects. Transportation to the factory or other designated facility for repairs of any products or items alleged defective shall, in all events, be the responsibility and at the cost of the owner.

EXCLUSIONS

Seller shall have no liability for and this warranty does not cover:

- A. Incidental, special or consequential damages, such as loss of the use of products, facilities or production, inconvenience, loss of time or labor expense involved in repairing or replacing the alleged defective Product.
- B. The performance of any Product under conditions varying materially from those under which such Product is usually tested under industry standards at of the time of shipment
- C. Any damage to the Product due to abrasion, erosion, deterioration, abnormal temperatures or the influence of foreign matter or energy.
- D. The design or operation of owner's plant or equipment or of any facility or system of which any Product may be made a part.
- E. The suitability of any Product for any particular application.
- F. Any failure resulting from misuse, modification not authorized by Seller in writing, improper installation or lack of or improper maintenance.
- G. Equipment furnished by the owner, either mounted or unmounted, or when contracted for by the owner to be installed or handled.
- H. Leakage or other malfunction caused by:
 - 1. Defective installations in general and specifically, any installation which is made:
 - a. in violation of applicable state or local plumbing housing or building codes,
 - b. contrary to the written instructions furnished with the unit
 - 2. Adverse local conditions in general and, specifically, sediment or lime precipitation in the tubes and/or headers or corrosive elements in the atmosphere.
 - 3. Misuse in general and, specifically, operation and maintenance contrary to the written instructions furnished with the unit, disconnection, alteration or addition of components or apparatus, not approved by Seller, operation with fuels or settings other than those set forth on the rating plate or accidental or exterior damage.
- I. Production of noise, odors, discoloration or rusty water.
- J. Damage to surrounding area or property caused by leakage or malfunction.
- K. Costs associated with the replacement and/or repair of the unit including: any freight, shipping or delivery charges, any removal, installation or reinstallation charges, any material and/or permits required for installation, reinstallation or repair, charges to return the boiler and or components. Seller's liability under this warranty shall not in any case exceed the amount paid for the Product found to be defective.

THIRD PARTY WARRANTIES

For goods or components not manufactured by Seller, the warranty obligations of Seller shall, in all respects, conform and be limited to one (1) year from the date of shipment.

SEVERABILITY

To the extent that any provision of this warranty would be void or prohibited under applicable law, such provisions shall be limited in effect to the minimum extent necessary to render the remaining provisions hereof enforceable.

No OTHER WARRANTIES

Seller makes no implied warranty of merchantability or fitness for a particular purpose or other warranties with respect to any products or services except as expressly set forth in this limited warranty.

Note: Rev. January 1, 2006

BOILER FIRE-TEST REPORT

**BOILER
FIRE-TEST REPORT**

Date _____

Boiler _____ Model _____

Installation _____ City _____

State _____ Zip Code _____ Contact _____ Phone _____

Installer Name _____ Type of Installation _____
(Hotel, School, Etc.)

Fuel Natural Gas _____ Propane _____

Outdoor Temperature Sensor Connected? Yes _____ No _____

1. Factory Fire-Test (Copy from Boiler Label):

Field Fire-Test:

Date: _____

	High	Low		High	Low
Inlet Gas	"w.c.	"w.c.	Inlet Gas	"w.c.	"w.c.
Oxygen (O2)	%	%	Oxygen (O2)	%	%
Carbon Dioxide (CO2)	%	%	Carbon Dioxide (CO2)	%	%
Carbon Monoxide (CO)	ppm	ppm	Carbon Monoxide (CO)	ppm	ppm
Gross Stack Temp	°F	°F	Nox	ppm	ppm
			Gross Stack Temp	°F	°F
			Combustion Air Temp	°F	°F
			Stack Press (exhaust)	"w.c.	"w.c.
			Main Flame Signal	Yes/No	Yes/No
			Efficiency	%	%
			Comb. Air Pres. (Intake)	"w.c.	"w.c.

- 2. Water Inlet Temperature °F Water Outlet Temperature °F
- 3. Flow Through Boiler GPM
- 4. Operating Temperature Setpoint °F (from internal or external control)
- 5. Stack Pressure (measured where stack exits boiler) "w.c. (High) "w.c. (Low)
- 6. Approximate Stack Lengths Ft. Horizontal Ft. Vertical Flue Pipe Diameter
- 7. Incoming Electrical Power Volts a.c. Less than one volt between neutral and ground
- 8. System Water pH Level
- 9. Comments

Performed by: _____
(Print Name)

Please return a copy to Harsco Industrial, Patterson-Kelley
155 Burson Street - East Stroudsburg, PA 18301
Phone: (570) 476-7261 - Fax: (570) 476-7247 - www.harscopk.com


WARRANTY

FIRE TEST REPORT

APPENDIX 2: BOILER ALTITUDE DERATE SCHEDULE

For installations over 2000 ft elevations, a derate schedule is applied. The boiler input rating must be reduced by 4% per 1000 ft.

This is illustrated using the following graph.



Derate procedure is as follows:

With the boiler at high fire, adjust the gas valves (*as described in section 3.10.4*) to get 5% O₂ in the flue gas. If this cannot be achieved, perform the following steps:

- If the O₂% is too high, then the inlet gas pressure should be adjusted to the minimum pressure allowed, typically 5" wc. The gas valve should be adjusted to obtain approximately 5% O₂. If the O₂% is still too high, the fan speed may be lowered. This procedure should only be performed by factory trained personnel.
- If the O₂% is too low, then the gas valve settings should be reduced.

This procedure is also described in Bulletin 06-08.

WATER QUALITY STANDARDS FOR HYDRONIC BOILERS USED IN MULTI-METAL SYSTEMS

HARSCO Industrial, Patterson-Kelley boilers are designed to be incorporated into any multi-metal hydronic heating system. All multi-metal hydronic systems require that attention be paid to water treatment. The chemical additives for any multi-metal system must be specifically formulated for use with all the various metals used in that system.

Any closed, hydronic heating systems should include a meter, to monitor water addition to the recirculating loop, and a filter, pursuant to ASHRAE Standard 189.1 and the AWT Handbook. Water added to a closed hydronic system should not exceed more than 10% of the system volume per year and meter readings should be recorded, at least monthly, to ensure system losses are minimized and corrective actions shall be taken when needed.

Treatment programs for multi-metal systems should meet or exceed the following generally accepted best practices water quality guidelines:

1. Proper cleaning and surface preparation must be completed prior to system start-up.
2. pH must be maintained in a range that is appropriate for the metals contained in the system (see chart below).
3. Total Alkalinity between 100-500 ppm as CaCO₃.
4. Filtration as per industry best practices.
5. Total suspended solids below 10 ppm.
6. Corrosion inhibiting compounds to protect metals at or below:
 - a. Aluminum <0.25 MPY
 - b. Copper <0.1 MPY, soluble copper <0.25 ppm
 - c. Steel <3.0 MPY According to ASTM D 2688
7. Addition of strong acids is not recommended.
8. Maintain Chlorides < 125 mg/l.

Prior to initiating any treatment program, a water sample of the proposed fill water should be sampled for analysis. Once filled and bled of air, a pH neutral, industrial cleaner for use in multi-metal systems should be used to clean the entire hydronic system. Samples of the system water with cleaner should be taken and analyzed to ensure proper cleaner strength. Once cleaned, the system should be flushed with fresh (fill) water until the system water is within 100 micro Siemens in conductivity of the fresh water. When flushing is complete, a treatment program that is designed for use in that multi-metal system, after consideration of the metals it contains, must be used. Treatment programs should also comply with the standard water quality guidelines listed above.

Multi-Metal Systems with Aluminum	Multi-Metal Systems with Stainless Steel	Multi-Metal Systems with Copper
Proper surface cleaning required	Proper surface cleaning required	Proper surface cleaning required
pH maintained between 6.0-8.5*	pH maintained between 6.6-8.5**	pH range may vary ***
Total Alkalinity 100-500 ppm as CaCO ₃	Total Alkalinity 100-500 ppm as CaCO ₃	Total Alkalinity 100-500 ppm as CaCO ₃
Best Practices Filtration	Best Practices Filtration	Best Practices Filtration
Suspended solids below 10 ppm	Suspended solids below 10 ppm	Suspended solids below 10 ppm
Corrosion rates below: 0.1 MPY copper 3.0 MPY steel 0.25 MPY aluminum	Corrosion rates below: 0.1 MPY copper 3.0 MPY steel 0.1 MPY sst ^	Corrosion rates below: 0.1 MPY copper 3.0 MPY steel Max. MPY other metals
Addition of strong acid not recommended	Addition of strong acid not recommended	Addition of strong acid not recommended
When freeze protection is required, automotive grade glycols are not recommended and decomposition products should be monitored and maintained below concentrations that present corrosive conditions. For existing boiler water systems, additional requirements and operational conditions may be required to mitigate pre-existing conditions.		
* Other system components may have more restrictive ranges.		
** Per Industry SST Heat Exchanger Manufacturers.		
** Copper has a broad range of acceptable pH and the other metallic components may require a tighter range.		
^ Per ASHRAE/AIA Presentation # 6017 2012 Winter Conference.		